

TC-401L TC-402L

RDP Thin Client

User's Guide



◆ 1. Hardware Overview

Front



Rear



2. Quick Setup

(1) Connecting the peripheral devices such as Monitor, Keyboard, Mouse, Speaker and USB device (for USB Model only) to THIN CLIENT terminal.

Note: you can use USB Keyboard and USB Mouse. If you want to plug in more than one USB device, please add an USB-HUB to transfer.



(2) Connect from THIN CLIENT terminal to HUB/Switch/Router with straight Ethernet cable or connect to PC directly with straight Ethernet cable.



(3) Connect Power Adapter.



(4) Insert installation CD into CD-ROM of Host PC, run setup.exe and follow the wizard.

(5) Reboot your Host PC. Wait until the PC fully boots up and logon.

- (6) Turn on your THIN CLIENT Terminal and wait until all lights are on.
- (7) Click Logon on the Menu Screen.
- (8) Windows/ Linux logon screen will appear.

For more information about installation and settings, refer to the detail contents of this user's guide.

CONTENTS

1. System Introductions	5
1.1 Introductions	5
1.2 Installing the Software	9
1.3 Setting up Network Configurations	.16
2. THIN CLIENT Terminal Management	.28
2.1 Auto Logon Function	.28
2.2 Set the screen resolution and Frequency	.29
2.3 Special setting	.31
2.4 Advanced setting	.34
2.5 THIN CLIENT Terminal Information	.36

♦ 1.System Introductions

♦ 1.1 Introductions

THIN CLIENT L-series are basics on SOC and embedded Linux system. It connects to the network through standard TCP/ IP protocols; the Host PC could be a Windows system or Linux system. It saves the cost of hardware and maintenance, and reduces the electricity consumption.

Characteristics of THIN CLIENT L-Series:

(1) Free to maintain

All the programs run on the standard PC, and the terminal just need to show the display and output and input data. Therefore, when the operating systems update, you no need to update and maintain the terminals.

(2) High Compatibility

Support many OS include: Windows VISTA, Windows 2008, Windows XP PRO, Windows Server 2003, Linux. Support standard RDP Protocols, so it can work at many environments.

Almost all applications in the standard PC can run on the terminal, and you also no need to do any modification of the terminal.

(3) Noninterference each other

The standard PC and all the terminals can work independently, and they will not influence each other even they work in the same application.

(4) Fine Smart Design

Only one book size design outlook just occupy little space in the office, and we also design the metal bracket to hang it back on the display screen monitor.

(5) Energy Efficiency

Compared with the standard PC 250W electricity consumptions, 5W for the terminal can help to save great energies.

(6) Support high Resolution & Wide Screen

Support 640x480, 800x600, 1024x768, 1280x720.... 16 bit color (65,536 colors)

(7) Avoid Noisy Working Environment

It is fanless design which makes you can have the quiet working environment.

(8) High Security

We adopt 128bits encryption tachniques to assure of the security for the input data of the user that transport through network.

Note: This product is intended to reduce H/W deployment and maintenance costs. Additional software licenses may be required by the software licensors. Please check your software user license agreement to ensure your continued compliance with such agreement.

Advantages Compare:

	Standard PC	THIN CLIENT L-series
Cost	 (1) One computer for one user. (2) Min 250watts power consumption for one standard PC. (3) Charge for the replacement & upgrade of the standard PC parts in every 2 to 3 years. 	 (1) One THIN CLIENT for each user and only one PC for a group. (2) Only 5 watts power consumption. (3) No charge for the parts of the terminal. Can update through internet.
Security	 (1) Easy to illegal data leakage & Exposure. (2) Easy destructed by Virus and computer hacking. 	(1) No USB Model doesn't utilize external storage.
Service/Maintenance	Have to control each individual computer.	Controlling just host computers highly effective centralized control (program installation, deletion, and maintenance)
Environment	Heats and noises from CPU, VGA, HDD, Power Supply Fan, Small working environment.	No noise, only pleasant and quiet working environment.
Portability	Not available.	Portable terminal can be connected with host computer anywhere when internet is ready.

Configuration:



Recommended Host PC System

systems:	host PC Configu	uration which a	oplies to Windows	XP, Windows 200	0,Windows 2003,	LINUX operating
Thin Client	1-3	4-6	7-10	11-20	21-30	31-40
Host PC CPU	1.3Ghz Pentium 4 above	2.4Ghz Pentium 4 above	3.0Ghz Pentium 4 above	3.2Ghz Pentium 4 above	2.53Ghz Core 2 Duo above	3Ghz Core 2 Duo above
Host PC Memory	512MB above	768MB above	1GB above	2GB above	3GB above	4GB above
Host PC Hard Drive	7200RPM above	7200RPM above	7200RPM above	7200RPM above	10000RPM above	10000RPM above
NOTE: you ci	in connect at mo	ost 20 sets SUND	E terminals in windo	ows xp, windows V	ista.	
Recommend I	host PC Configu	aration which a	oplies to Windows	Vista, Windows 2	008 operating sys	tems:
	1-3	4-6	7-10	11-20	21-30	31-40
Thin Client						
Thin Client Host PC CPU	3.0Ghz Pentium 4 above	3.2Ghz Pentium 4 above	2.53Ghz Core 2 Duo above	3Ghz Core 2 Duo above	2.33Ghz Core 2 Quad above	2.5Ghz Core 2 Quad above
Host PC CPU Host PC Memory	3.0Ghz Pentium 4 above 1GB above	3.2Ghz Pentium 4 above 2GB above	2.53Ghz Core 2 Duo above 3GB above	3Ghz Core 2 Duo above 4GB above	2.33Ghz Core 2 Quad above 5GB above	2.5Ghz Core 2 Quad above 6GB above

Product Specifications:

- Power: INPUT AC110V ~ AC240V 50/60 Hz, OUTPUT DC 5V/ 2A
- **Size:** 140mm(W) x 34mm(H) x 120mm(D)
- Weight: 500g
- Port: DC Power Jack, Speaker Jack, PS2 Keyboard Port, PS2 Mouse Port,
 - Ethernet (RJ-45) Port, Video Monitor Port, USB Port. (USB for USB Model only)
- **Protocol**: NetPoint 5.1, RDP
- **Supported OS:** Windows VISTA, Windows XP Professional, Windows 2008, Windows Server 2003, LINUX

\diamond 1.2 Installing the Software

• 1.2.1 Installing Netpoint Software

1. Turn on the Host PC and insert the Software Installation CD into the CD drive after your computer boots up.

2. The installation program will start automatically. If not, browse the CD, and double click "setup.exe".

3. Please make sure to DISABLE or UNINSTALL any **Anti-Virus** or **Firewall** software that may be running in the background. Security software or these types softwares have been tested and known to interfere with the installation and operation of our product. Click "Next".

🐻 Installing Net	Point5.1
	Welcome to the NetPoint5.1 Installation! This setup program will install NetPoint5.1 on your computer. Click Cancel if you do not want to install this application. Click Next to continue the installation. WARNING: This program is protected by international copyright law and treaties. Unauthorized reproduction or distribution of this program, or any portion of it, may result in severe civil and criminal penalties and will be prosecuted to the maximum extent of the law.
CreateInstall Fr	Next > Cancel

4. Read the contents of the "readme" file and click "Next".



5. Once the license agreement window appears, check "I agree with the above terms and conditions" and then click "Next". If you do not agree with the license agreement, click "Cancel" to finish the process.

🐻 Installing NetPoint5.1
License Agreement To proceed with the installation, you must accept this License Agreement. Please read it carefully.
END USER LICENSE AGREEMENT IMPORTANT-READ CAREFULLY: This End-User License Agreement ("EULA") is a legal agreement between you (either an individual or a single entity) and NetPoint Co. Ltd ("NetPoint"). for the software product identified above, which includes computer software and may include associated media, printed materials, and "online" or electronic documentation (collectively, "SOFTWARE PRODUCT"). By installing, copying, or otherwise using the SOFTWARE PRODUCT, you agree to be bound by the terms of this EULA. If you do not agree to the terms of this EULA, you may not use the SOFTWARE PRODUCT. SOFTWARE PRODUCT LICENSE
The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The
CreateInstall Free

6. Select the installation default folder and click "Next". The "program Files" is the default installation folder.

🖏 Installing NetPoint5.1	K
Destination folder Select a destination folder where NetPoint5.1 will be installed.	
Setup will install files in the following folder. If you would like to install NetPoint5.1 into a different folder then click Browse and select another folder.	
Space required: 312.78KB	
– CreateInstall Free	
< Back Next > Cancel	

7. Netpoint has been successfully installed! Click "Finish" to complete the installation.



8. Click "Yes" to restart your computer now.



9.Make up Firewall Setup:

For XP, Windows 2003 Server:

Restart the computer, When Windows Security Alert wizard window appears, click "Unblock".

😺 Wine	dows Sec	urity Alert 🛛 🔁
۲	To help some fea	protect your computer, Windows Firewall has blocked atures of this program.
Do you	ı want to l	keep blocking this program?
	Name:	netpoint
	Publisher:	Unknown
		Keep Blocking Unblock Ask Me Later
-		
Window	s Firewall h	as blocked this program from accepting connections from the
unblock	it. <u>When st</u>	nould I unblock a program?

For Windows VISTA, Windows 2008:

(1). Click "Start" and click "Control Panel".

Control Panel +					- + Search	h		Q
File Edit View Tools Help								
Control Panel Home Classic View 	Name	Category	AutoDiau	Backup and	Calar	Date and	Default	*
	Hardware	Tools		Restore C	Management		Programs	
	Device Manager	Ease of Acce	Folder Options	Fonts	Game Controllers	Indexing Options	Internet Options	н
	iSCSI Initiator	Keyboard	Mouse	Network and Sharing Ce	Offline Files	Parental Controls	Personaliz	
	Phone and Modem	Power Options	Printers	Programs and Features	Regional and Language	Scanners and Cameras	Security Center	
	Sound	Sync Center	System	Taskbar and Start Menu	User Accounts	VMware Tools	Windows CardSpace	Ŧ

(2). Double Click "Windows Firewall"

Control Panel +	6			,	• + Searc	h		Q
File Edit View Tools Help								
Control Panel Home	Name	Category	-			~		^
Classic View	Device Manager	Ease of Acce	Folder Options	Fonts	Game Controllers	Indexing Options	Internet Options	
	e,	۷	Ĩ)9			
	iSCSI Initiator	Keyboard	Mouse	Network and Sharing Ce	Offline Files	Parental Controls	Personaliz	
		1			Ð		1	
	Phone and Modem	Power Options	Printers	Programs and Features	Regional and Language	Scanners and Cameras	Security Center	
					S		3	н
	Sound	Sync Center	System	Taskbar and Start Menu	User Accounts	VMware Tools	Windows CardSpace	
	盟			4				
77	Windows Defender	Windows Firewall	Windows Sidebar	Windows Update				+

(3). Click "Change settings"



(4) Select "Exceptions" tab



Turn Windows Firewall	Windows Firewall Settings	X	
off	General Exceptions Advanced		ining access to you
Allow a program throug Windows Firewall	Exceptions control how programs communicate through Windows Firewall. program or port exception to allow communications through the firewall.	Add a	,
	Windows Firewall is currently using settings for the public network location What are the risks of unblocking a program?	e .	
	To enable an exception, select its check box:		ge settings
	Program or port	*	
	Distributed Transaction Coordinator		
	File and Printer Sharing		a second as
	iSCSI Service		c network
		H	
1	Netlogon Service		
110	MetPoint	1	
11/2			
1111			
111 1			
	Remote Event Log Management		
	Bomoto Schodulad Taaka Managament	*	
	Add program Add port Properties Delete		
See also	Votify me when Windows Firewall blocks a new program		
Security Center			

(5). Select "Remote Desktop", Click "OK" to save.

10. At this moment you can enjoy THIN CLIENT!

Note

For Linux installation, please refer to the documents in Installation CD.

• 1.2.2 Uninstall Netpoint Software

To uninstall the software, follow these steps:

1. Click "Start", click "All Programs", click "NetPoint5.1", and then click "Uninstall".

2. When NetPoint remove wizard window appears, click "Yes".

NetPoint Uninstall
Are you sure you want to completely remove NetPoint and all of its components?
Yes No

3. Click "OK" to complete the uninstallation.

NetPoint Uninstall 🛛 🛛 🔀
All components have been removed.
ОК

4. After the programs have been removed from your computer, Please **restart** your computer.

♦ 1.3 Setting up Network Configurations

If your computer is using Windows® XP or server 2003 or 2008 or Vista and has a network adapter, you have to configure the network to connect with any THIN CLIENT terminal(s). To configure your computer's network configurations, please refer to the following:

1.3.1 Connecting to the Network by Using a Cable/DSL Router (Support 100 Mbit Switching and DHCP Function)

If you use a Cable/DSL router, you can use dynamic IP addresses. (To use dynamic IP addresses, the router must support DHCP or a dynamic IP address allocation function) If you want to use static IP addresses when using a Cable/DSL router, refer to "Connecting by using a switch".

1. Click "Start" and click "Control Panel". (In Windows® 2003, click "Start", click "Settings", and then click "Control Panel")

2. Click "Network and Internet Connections", and then click "Network Connections". (In Windows® 2003, double click "Network and Dial-up Connections")

3. Right click on the LAN adapter icon and select "properties". (In Windows® 2003, right click on the LAN adapter icon and select "properties")

4. Click "Internet Protocol (TCP/IP)" and click the "properties". (In Windows® 2003, click "Internet Protocol (TCP/IP)" and click the "Properties")

onnect using: IIII SiS 900-Based PCI Fa	ist Ethernet Ad	Configure
nis connection uses the foll	lowing items:	
 ✓ I Client for Microsoft I ✓ I File and Printer Sha ✓ I QoS Packet Sched ✓ Internet Protocol (T 	Networks ring for Microso uler CP/IP)	ft Networks
I <u>n</u> stall	<u>U</u> ninstall	Properties
Description Transmission Control Proto wide area network protoco	ocol/Internet Pr ol that provides cted networks	otocol. The default communication

5. Check "Obtain an IP address automatically" and "Obtain DNS server address automatically," and then click "OK".

General	Alternate Configuration			
You ca this cap the app	n get IP settings assigner bability. Otherwise, you ne propriate IP settings.	l automatically ed to ask you	if your ne r network	etwork supports administrator for
<u>0</u>	btain an IP address autor	natically		
	se the following IP addre:	:s:		
<u>I</u> P ad	ddress:			10 m
Sybr	net mask:			
Defa	ault gateway:		× - 1	
<u>⊚ 0</u>	<u>b</u> tain DNS server addres:	automatically		
OU:	s <u>e</u> the following DNS ser	ver addresses:		
Prefe	erred DNS server:			
Alter	nate DNS server:			
				Advanced
		ſ	ОК	Cance

6. Turn on the THIN CLIENT terminal for configuration settings. Click the "Setup".



7. In the "Local" tab, chick " Get from DHCP Server", and then click "Save".

soc	
Terminal IP • Get from DHCP Server. • Set a Static IP Address. Input IP: 192.168.1.23 Screen Res. 800x600 • 60 Hz • 75 Hz Save Close	

8. In the "Server" tab, "Search All Servers in LAN" would be activated as the default setting for automatic connection to the Host PC. If you want to connect directly into the system, please fill in the "User name" and "Password", and then click "Save".



9. If you finished the setting, click "Save", Click "Find" to search servers and then "Logon".



10. Your THIN CLIENT terminal should be connected to the Host PC. You are now ready to use your THIN CLIENT terminal.

1.3.2 Connecting by Using a Switch (Supports 100 Mbit/sec Switching)

To connect by using a switch, you have to set a static IP address on both the THIN CLIENT terminal and the Host PC. To configure an IP address as static, follow these steps:

1. Click "Start" and click "Control Panel". (In Windows® 2003, Click "Start", click "Settings", and then click "Control Panel")

2. Click "Network and Internet Connections", and then click "Network Connections". (In Windows® 2003, double click "Network and Dial-up connections")

3. Right click on the LAN adapter icon and select "Properties". (In Windows® 2003, right click on the LAN adapter icon and select "Properties")

4. Click "Internet Protocol (TCT/IP)" and click the "Properties". (In Windows® 2003, click "Internet Protocol (TCT/IP)" and click the "Properties")

General	Authentication	Advanced	
Connec	t using:		
B S	iiS 900-Based Pi	CI Fast Ethernet Ad	Configure
This c <u>o</u>	nnection uses th	e following items:	
	Client for Micro File and Printer QoS Packet Si Internet Protoc	Solit Networks Sharing for Microso cheduler ol (TCP/IP)	oft Networks
	nstall	<u>U</u> ninstall	Properties
Tran: wide acros	smission Control area network pr ss diverse interco	Protocol/Internet Protocol that provides onnected networks.	rotocol. The default communication
🗌 Shoj 🔽 Noti	<u>w</u> icon in notifica fy <u>m</u> e when this	tion area when con connection has limit	nected ed or no connectivity
		_	

5. Check "Use the following IP address" and input the address of the IP address, subnet mask, and Default Gateway, and then click "OK".

You can get IP settings assigned his capability. Otherwise, you ne he appropriate IP settings.	d automatically if your network supports eed to ask your network administrator for
O Obtain an IP address autor	natically
OSE Use the following IP address	18.
IP address:	192.168.1.100
Sybnet mask:	255 . 255 . 255 . 0
Default gateway:	192.168.1.1
Obtain DNS server address	automatically
O Use the following DNS service of the service	ver addresses:
Preferred DNS server:	
<u>A</u> lternate DNS server:	
	Advanced

6. Turn on the THIN CLIENT terminal for configuration. Click the "Setup".

Maras	
Sam	
Logon Eind Setup Info	

7. In the "Local" tab, check "Set a Static IP Address" and input the IP address you want to use.



8. In the "Server" tab, select "Auto Logon when Power "On", and input the IP address of the HOST PC on the Terminal Server Network address. If you want to connect directly into the system, please fill in the "User name" and "Password", and then click "Save".

Server © Search All Servers in LAN © Auto Logon when Power On. Input IP: 192.168.1.100 User Name: p PassWord : *	

9. If you are finished with the settings, click "Save". Click "Find" to search servers and then "Logon".



10. Your THIN CLIENT terminal should be connected to the Host PC. You are now ready to use your THIN CLIENT terminal.

1.3.3 Directly Connecting the THIN CLIENT terminal to a Host PC



• Host PC has one LAN adapter and no connection to the Internet

1. Click "Start" and click "Control Panel". (In Windows® 2003, click "start", click "settings", and then click "Control Panel")

2. Click "Network and Internet Connections", and then click "Network Connections". (In Windows® 2003, double click "Network and Dial-up connections")

3. Right click on the LAN adapter icon and select "Properties". (In Windows® 2003, right click on the LAN adapter icon and select "Properties")

Note

If the LAN adapter of Host PC has AUTO-MDIX function, you can connect Terminal to the Host with cross cable, otherwise you must use straight cable.

To connect several THIN CLIENT systems to a single Host PC, you must have equal number of LAN adapters to the number of THIN CLIENT terminals that will be connected to the Host PC.

4. Click "Internet Protocol (TCP/IP)" and click the "Properties".

5. Check "Use the following IP address" and input as below and click "OK". (For example, IP Address is 192.168.1.100 and Subnet mask is 255.255.255.0. According to the Host PC's configuration, the IP address should be different)

6. Turn on the THIN CLIENT terminal for configuration settings. Click the "Setup".



7. In the "Local" tab, check "Set a Static IP Address" and input IP address as below. (For example, IP address is 192.168.1.23 According to Host PC's configuration, the IP address should be different)



8. In the "Server" tab, select "Auto Logon when Power On, and input the IP address of the HOST PC on the Terminal Server Network address. If you want to connect directly into the system, please fill in the "User name" and "Password", and then click "Save".

Server Periph Advanced Server Search All Servers in LAN Auto Logon when Power On. Input IP: 192.168.1.100	
User Name: p PassWord : * Save Close	

9. If you have finished the settings, click "Save", Click "Find" to search servers and then "Logon".



10. Your THIN CLIENT terminal should be connected to the Host PC. You are now ready to use your THIN CLIENT terminal.

• Host PC has two LAN adapters and of the LAN adapter connected to the Internet

If your Host PC has only one LAN adapter connected to the Internet, you have to install the LAN adapter to connect the THIN CLIENT terminal to your Host PC. To connect the THIN CLIENT terminal to your Host PC, refer to "Host PC has one LAN adapter and no connection to the Internet", the setting of the Internet, contact to your ISP. (Internet Service Provider)

The setting of the Internet, contact your ISP. (Internet Service Provider)

1. Click "Start" and click "Control Panel". (In Windows® 2003, click "Start", click "Settings" and then click "Control Panel") Click "Network and Internet Connections", and then click "Network Connections". (In Windows® 2003, double click "Network and Dial-up Connections")

2. Right click on the LAN adapter icon and select "Properties". (In Windows® 2003, right click on the LAN adapter icon and select "Properties" In the "Advanced" tab, check "Allow other network users to connect through this computer's Internet connection" in Internet Connection Sharing and click "OK". (In Windows® 2000,in the "Sharing" tab, check "Enable Internet Connection Sharing for this connection" and click "OK")

3. Click "Yes" to restart your computer.

4. For the next settings, refer to "Host PC has one LAN adapter and no connection to the Internet".

Note

You have to know the allocated IP address that the Host PC received automatically. You can see the IP address of the Host PC as follows:

1 Click "start" on the Host PC. Click "Run".

2 Type "cmd" in the input box. The DOS prompt window will appear.

Run	? 🛛
	Type the name of a program, folder, document, or Internet resource, and Windows will open it for you.
<u>O</u> pen:	command
	OK Cancel Browse

3 Type "ipconfig" in the DOS command line and press Enter. IP address, subnet mask, and Gateway that was allocated to the Host PC will be displayed on the screen.



2. Thin Client Terminal Management

Thank you for buying the THIN CLIENT terminal(s). This User's guide tells you how to use and configure the THIN CLIENT terminal(s).

Note

This user's guide provides instructions of THIN CLIENT (s) connection function and management. Its is recommended to read this user's guide carefully before using this new program.

♦ 2.1 Auto Logon Function

With the "Auto Logon" function, you can easily connect to a Host PC without using the THIN CLIENT main setup screen.

1. Turn on your THIN CLIENT device power.

2. Next, you will automatically go into the Windows desktop screen without having to press the "Logon".

Introducing the Auto Logon setup

• Setting up your Auto Logon menu from THIN CLIENT main setup

1. Click "setup" to setup your connection menu.



2. a) Click "Server" tab.

- b) Click "Auto Logon When Power On".
- c) Input the IP address of the HOST PC on the Terminal Server Network address.
- d) Fill in the "User name" and "Password".



6. If you have finished the settings, click "Save", then restart your THIN CLIENT terminal.7. After restart the THIN CLIENT terminal you will automatically go into the Windows desktop screen.

Note

Depending on the model, your THIN CLIENT's functions may look slightly different than those from this THIN CLIENT user's guide.

♦ 2.2 Set the screen Resolution and Frequency

THIN CLIENT itself has ability to set screen resolution and Frequency. In the initial screen of THIN CLIENT, select "Setup" \rightarrow "Local" and screen same as the figure shown above appears.(Resolution and Frequency in the figure may vary depending on the product). Resolution and Frequency selected in this way becomes the basis when logging on Windows and even if user sets different Resolution and Frequency in Windows, resolution and Frequency set in THIN CLIENT will override when Windows is logoff and on again. Therefore, resolution and Frequency user wants should be set in THIN CLIENT. Click "Save" after selecting desired resolution and Frequency.



You have selected to change the screen resolution. To make this effect, the terminal will restart immediately. Click "Yes" to restart the terminal.

		Local Server Periph Advanced	
	8	You have selected to change the screen resolution. To make this effect,the terminal will restart immediately. Are you sure?	
		Yes No Cancel	
- 23		Save Close	

Note

In case of change resolution between standard screen and widescreen, you need power off and restart manually.

After restart, your desktop has been reconfigured. If you can see this display and accept, click

"Yes" to keep these settings. Otherwise, if your display cannot support this configuration, maybe you can see nothing. Just press <ENTER> or <Space> or just only wait, it will go back to the previous configuration.



♦ 2.3 Peripheral device setting

Click "setup" \rightarrow "Periph", Here you can settings enable or disable THIN CLIENT Terminal USB Disk, Local Sound and Mouse pointer speed. If you are finished with the settings, click "Save".

	soc	Perinh		
	USB Disk © Enable . © Disable . Mouse Slow	Loca © Er © Di	al Sound – nable . sable . — Fast	
Contraction of the second second				

USB Disk setting

This option can control the Enable/ Disable access of the USB disk, only USB Model has this function. When you choose Enable, you can access the USB disk; otherwise, you can not..

soc Image: Social Server Local Server Periph Advance USB Disk Local Sound Image: Social	
Save Close	

Note

When logon to host PC, you can plug in a USB disk at anytime, after plug in, please wait for 5 seconds before access it by clike the "Network Driver" icon in "My Computer". If you want to plug it out, make sure to logout or just disconnect from the host PC, and then plug it out. Otherwise the data maybe damaged!

Local Sound setting

This option can control the Enable/ Disable use of the Local Sound, When you choose Enable, the Local Sound can work, but when you choose Disable, then Local Sound can not work.

	50C	
	Local Server Periph Advanced USB Disk C Enable . Disable . Mouse Slow Fast	
	<u>Save</u> <u>Close</u>	
A CONTRACT AND A CONTRACT OF A CONTRACT		

Mouse pointer speed setting

This option can be adjusted THIN CLIENT terminal mouse pointer speed.

00	
orver Periph Advanced	
Isk Local Sound ole . Close ble . Close	
	e . © Enable . le . © Disable . Fast Save Close

Advanced setting A

Setup Password

Turn on the THIN CLIENT terminal for configuration. Click the "Setup". In the "Advanced" tab, select "Protect Setting", and then click "Modify"

soc Local Server Periph Advanced	
Administrator Exec Setup Password	
<u>Save</u> <u>Close</u>	

	■ soc	
	Exec Setup Password	
Colorence and the second second		

Input the Password you want to use. If you have finished the settings, click "Save". You should remember the "Password". If not, you can't execute management setting.

Local Server Periph Advanced
Administrator Exec
Setup Password O not Use Password. Protect Setting.
Discard Save Close

If you have already set the password, when you setting THIN CLIENT again, you need to input the password.



Note *Please store the password for safekeeping.*

♦ 2.5 THIN CLIENT Terminal Information

Showing the information of the THIN CLIENT terminal.

