

## Firmware Upgrade methods

Please be sure to check the firmware upgrade steps to load the firmware into machine properly for evaluations.

**ATA:** VIP-156/VIP-156PE/VIP-157/VIP-157S

**IP Phone:** VIP-154T/VIP-154PT/VIP-154NT

a) Log in ATA (or IP Phone) via Microsoft Internet explorer web browser, and insert [http://ATA \(or IP Phone\) address/update.htm](http://ATA (or IP Phone) address/update.htm) in the address bar.

b) Unzip the attachment, get the machine \*.rom file, and select update "All ROM", and browse to the firmware location.

c) After firmware loaded, the unit will be reboot, it is suggested to load the factory default settings to activate the new configurations.

**Note:** Default IP address of the official firmware is <http://192.168.0.1>;  
Login name/ password is **root/null** (no password)

\*\*\*\*\*

**Thanks for choosing PLANET products.**

**Best Regards ,**

**PLANET Tech SupportTeam**

**VoIP Technical Service: support\_voip@planet.com.tw**