


## Firmware Upgrade Procedure for VIP-150PT/ VIP-153PT / VIP-153T

### (Example on VIP-150PT)

1) Please find the latest firmware on our server, and be sure to refer to the steps carefully to complete the firmware upgrade to the latest release for evaluations:

2) The **FTP** server (such as File Transfer Server from GlobalScape.com) is required to complete VIP-150PT firmware upgrade process. Please be sure to put the firmware file and double check the FTP server access rules (predefine a user account with name/password: admin/123), so that the VIP-150PT can upgrade the firmware successfully through the access rule and file location.

3) Please login VIP-150PT via web browser and insert the FTP server IP address/firmware file name to complete the firmware upgrade, please click on the "**DONE**" icon to apply settings, and reboot the machine to make the settings effective.



The screenshot displays the Planet VIP-150PT Configuration Menu. On the left is a dark blue sidebar with the Planet logo and a list of menu items: Overview, Network Configuration, SIP Configuration, Phone Configuration, and System Configuration (highlighted in green). The main content area is titled 'System Configuration' in red. Under the 'Firmware Upgrade' section, there are two input fields: '1. FTP Server:' and '2. Image File Name:'. Both fields are circled in blue. To the right of the second field is a 'DONE' button. Below these fields is an 'Upgrade Now' button. The 'Configuration Backup / Restore' section below it contains a single input field for '1. FTP Server IP Address:'.

4) Please click on the "**Upgrade Now**" icon to proceed with the updating process.