


## Firmware upgrade procedure for VIP-158

- A) Please find the latest firm ware on our website, and be sure to refer to the steps carefully to complete the firm ware upgrade to latest release evaluations.
- B) Unzip the attachment, get the **FW-VIP158vxxx\_xxx.bin** file; then execute TFTP program, click <**Browse**> button assign the firm ware location.  
(This parts might vary on different kind of TFTP programs)



- C) Log in ATA via Microsoft Internet Explorer web browser, parts of the "**Provision**" please insert "TFTP Server IP" and "Firm ware", then click <**SUBMIT**> button save modification.

Provision	
TFTP Provision	Disable ▾
TFTP Server IP	192.168.1.189
Firmware	FW-VIP158v10222_2008
Firmware Upgrade	UPGRADE

- D) After modification saved success, click <**UPGRADE**> button to loading firm ware into machine, it is suggest to load factory settings to activate the new configurations.

### NOTE :

Default IP address is <http://192.168.0.1>

Login name / password is **root / null**

\*\*\*\*\*

**Thanks for choosing PLANET products.**

**Best Regards ,**

**PLANET Tech Support Team**

**VoIP Technical Service: support\_voip@planet.com.tw**