


Firmware Upgrade Procedure:

- 1) Please find the latest firmware on our server, and be sure to refer to the steps carefully to complete the firmware upgrade to the latest release for evaluations:
- 2) Be sure to update the firmware files in correct sequence (login machine via web browser **HTTPs** session and find the **PBX firmware** in the **system** menu to complete the firmware upgrade)




- 3) Please click on the "**Browse**" icon to select the file, once the firmware file is entered, please click on the "**Upgrade**" icon to proceed with the updating process.

For example:

1st) E2K_ xxxxx-xxxxxxxxxxx.bin (5 MB)



Please wait for few minutes till machine finishes loading firmware and rebooting.



2nd) E2K_ xxxxx-xxxxxxxxxxx.bin (3 MB)

After loading the firmware files, it is suggested to load the factory default settings to activate the new configurations. Power off the machine, press the RESET button on

the front panel; power on machine, and wait 3 minutes till machine configurations are fully loaded for evaluations.