


DPC-D211

Firmware updating

1. Tools and Connection


USB-485 Converter is needed and connection is as below, Also remember to power the door station.



2. Firmware Updating

2.1 Install the driver for USB-485 converter on the computer (refer to the manual)

Run the software IAP on the computer




Note: Language: can be set to Chinese or English, it was English by default.

Com Port: need to be set to the right port


Baud: 38400, take the default value

File Name: The software which is to be flashed into the DPC-D211


2.2 Set the right com port for the USB-485 Converter, here it is com4



2.3 Select the software for the DPC-D211, click open to confirm



2.4 Click on update button to start the updating



When the updating is finished, click OK on the pop-up dialog.



Note: When updating is in process, make sure power supply is stable.
Any power down may cause damage to the CPU of the unit.