



802.11g Wireless Broadband Router

WRT-413

User's Manual



Copyright

Copyright© 2004 by PLANET Technology Corp. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of PLANET.

PLANET makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1.Reorient or relocate the receiving antenna.
- 2.Increase the separation between the equipment and receiver.
- 3.Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4.Consult the dealer or an experienced radio technician for help.

FCC Caution:

To assure continued compliance.(example-use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the Following two conditions: (1) This device may not cause harmful interference, and (2) this Device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm(8 inches) during normal operation.

R&TTE Compliance Statement

This equipment complies with all the requirements of DIRECTIVE 1999/5/CE OF THE EUROPEAN PARLIAMENT AND THE COUNCIL OF 9 March 1999 on radio equipment and telecommunication terminal Equipment and the mutual recognition of their conformity (R&TTE)

The R&TTE Directive repeals and replaces in the directive 98/13/EEC (Telecommunications Terminal Equipment and Satellite Earth Client Equipment) As of April 8,2000.

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

Revision

User's Manual for PLANET 54Mbps Wireless Broadband Router

Model: WRT-413

Rev: 1.0 (March. 2004)

Part No. EM-WRT413v1

Table of Contents

CHAPTER 1 INTRODUCTION	1
WRT-413 Features	1
Package Contents	3
Physical Details	4
CHAPTER 2 INSTALLATION	6
Requirements	6
Procedure	6
CHAPTER 3 SETUP	8
Overview	8
Configuration Program	9
Setup Wizard	11
LAN Screen	14
Wireless Screen	16
Password Screen	19
CHAPTER 4 PC CONFIGURATION	21
Overview	21
Windows Clients	21
Macintosh Clients	33
Linux Clients	33
Other Unix Systems	33
Wireless Client Configuration	34
CHAPTER 5 OPERATION AND STATUS	35
Operation	35
Status Screen	35
Connection Status - PPPoE	36
Connection Status - PPTP	39
Connection Status - L2TP	40
Connection Status - Telstra Big Pond	41
Connection Details - SingTel RAS	42
Connection Details - Fixed/Dynamic IP Address	45
CHAPTER 6 ADVANCED FEATURES	47
Overview	47
Access Control	47
Dynamic DNS (Domain Name Server)	54
Advanced Internet Screen	56
Virtual Servers	60
WAN Port Configuration	64
CHAPTER 7 ADVANCED ADMINISTRATION	67
Overview	67
Config File	68
Logs	69

Network Diagnostics.....	71
Options.....	72
PC Database.....	74
Remote Admin	78
Routing.....	79
Security	83
Upgrade Firmware.....	85
APPENDIX A TROUBLESHOOTING	86
Overview	86
General Problems	86
Internet Access	86
Wireless Access.....	87
APPENDIX B ABOUT WIRELESS LANS	88
Modes	88
BSS/ESS.....	88
Channels	88
WEP	89
Wireless LAN Configuration	89
APPENDIX C SPECIFICATIONS	90
Multi-Function WRT-413	90
Wireless Interface	90
Regulatory Approvals	91

Chapter 1

Introduction

1

This Chapter provides an overview of the WRT-413's features and capabilities.

Congratulations on the purchase of your WRT-413. It is a multi-function device providing the following services:

- **Shared Broadband Internet Access** for all users.
- **4-Port Switching Hub** for 10Base-T or 100Base-TX connections.
- **Wireless Access Point** for 802.11b and 802.11g Wireless Clients.




Figure 1: WRT-413

Features

WRT-413 incorporates many advanced features, carefully designed to provide sophisticated functions while being easy to use.

Internet Access Features

- **Shared Internet Access.** All users on the LAN or WLAN can access the Internet through the WRT-413, using only a single external IP Address. The local (invalid) IP Addresses are hidden from external sources and this process is called NAT (Network Address Translation).
- **xDSL & Cable Modem Supported.** The WRT-413 has a 10/100Base-TX Ethernet port for connecting xDSL or Cable Modem. All popular xDSL and Cable Modems are supported. SingTel RAS and Big Pond (Australia) login support is also included.
- **PPPoE, PPTP, SingTel RAS and Telstra Big Pond Support.** The Internet connection supports PPPoE (PPP over Ethernet), PPTP (Peer-to-Peer Tunneling Protocol), SingTel RAS and Telstra Big Pond (Australia), as well as "Direct Connection" type services. Unnumbered IP with PPPoE is also supported.
- **Fixed or Dynamic IP Address.** On the Internet (WAN port) connection, the WRT-413 supports both Dynamic IP Address (IP Address is allocated on connection) and Fixed IP Address.

Advanced Internet Functions

- **Communication Applications.** Support for Internet communication applications, such as interactive Games, Telephony, and Conferencing applications, which are often difficult to use when behind a Firewall, is included.

- **Special Internet Applications.** Applications which use non-standard connections or port numbers are normally blocked by the Firewall. The ability to define and allow such applications is provided, to enable such applications to be used normally.
- **Virtual Servers.** This feature allows Internet users to access the Internet services on your LAN. The required setup is quick and easy.
- **DDNS Support.** DDNS (Dynamic DNS) allows Internet users to connect to Virtual Servers on your LAN using a domain name, even if your IP address is not fixed.
- **Multi-DMZ.** For each legal IP address allocated to you, one (1) PC on your local LAN can be configured to allow unrestricted 2-way communication with Servers or individual users on the Internet. This provides the ability to run programs which are incompatible with Firewalls.
- **URL Filter.** Use the URL Filter to block access to undesirable Web sites by LAN users.
- **Internet Access Log.** See which Internet connections have been made.
- **Access Control.** Using the Access Control feature, you can assign LAN users to different groups, and determine which Internet services are available to each group.
- **VPN Pass through Support.** PCs with VPN (Virtual Private Networking) software using PPTP, L2TP and IPSec are transparently supported - no configuration is required.

Wireless Features

- **Standards Compliant.** The WRT-413 complies with the IEEE802.11g (DSSS) specifications for Wireless LANs.
- **Supports both 802.11b and 802.11g Wireless Clients.** The 802.11g standard provides for backward compatibility with the 802.11b standard, so both 802.11b and 802.11g Wireless clients can be used simultaneously.
- **Speeds to 54Mbps.** All speeds up to the 802.11g maximum of 54Mbps are supported.
- **WEP (Wired Equivalent Privacy) support.** Supports WEP64 and WEP128.
- **WPA-PSK support.**
- **Wireless MAC Access Control.** The feature can check the MAC address of each wireless client to allow access your LAN.
- **Simple Configuration.** If the default settings are unsuitable, they can be changed quickly and easily via the web configuration.

LAN Features

- **4-Port Switching Hub.** The WRT-413 incorporates a 4-port 10/100Base-TX switching hub, making it easy to create or extend your LAN.
- **DHCP Server Support.** Dynamic Host Configuration Protocol provides a dynamic IP address to PCs and other devices upon request. The WRT-413 can act as a **DHCP Server** for devices on your local LAN and WLAN.
- **Multi Segment LAN Support.** LANs containing one or more segments are supported, via the WRT-413's RIP (Routing Information Protocol) support and built-in static routing table.

Configuration & Management

- **Easy Setup.** Use your WEB browser from anywhere on the LAN or WLAN for configuration.
- **Configuration File Upload/Download.** Save (download) the configuration data from the WRT-413 to your PC, and restore (upload) a previously-saved configuration file to the WRT-413.
- **Remote Management.** The WRT-413 can be managed from any PC on your LAN. And, if the Internet connection exists, it can also (optionally) be configured via the Internet.
- **Network Diagnostics.** You can use the WRT-413 to perform a **Ping** or **DNS lookup**.

- **UPnP Support.** UPnP (Universal Plug and Play) allows automatic discovery and configuration of the WRT-413. UPnP is supported by Windows Me, XP, or later.

Security Features

- **Password - protected Configuration.** Optional password protection is provided to prevent unauthorized users from modifying the configuration data and settings.
- **Wireless LAN Security.** WEP (Wired Equivalent Privacy) is supported, as well as Wireless access control to prevent unknown wireless clients accessing your LAN.
- **NAT Protection.** An intrinsic side effect of NAT (Network Address Translation) technology is that by allowing all users to share a single IP address, the location and even the existence of each PC is hidden. From the external viewpoint, there is no network, only a single device - the WRT-413.
- **Stateful Inspection Firewall.** All incoming data packets are monitored and all incoming server requests are filtered, thus protecting your network from malicious attacks from external sources.
- **Protection against DoS attacks.** DoS (Denial of Service) attacks can flood your Internet connection with invalid packets and connection requests, using so much bandwidth and so many resources that Internet access becomes unavailable. The WRT-413 incorporates protection against DoS attacks.

Package Contents

The following items should be included:

- 1 x WRT-413
- 1 x Power Adapter
- 1 x Quick Installation Guide
- 1 x CD-ROM (includes manual)
- 1 x External Antenna

If any of the above items are damaged or missing, please contact your dealer immediately.

Physical Details

Front-mounted LEDs




Figure 2: Front Panel

Power LED	On - Power on. Off - No power.
Status (Red) LED	On - Error condition. Off - Normal operation. Blinking - This LED blinks during start up, and during a Firmware Upgrade.
LAN LEDs	For each port, there are 2 LEDs <ul style="list-style-type: none">• LNK/ACT<ul style="list-style-type: none">• On - Corresponding LAN port is active.• Off - No active connection on the corresponding LAN port.• Flashing - Data is being transmitted or received via the corresponding LAN port.• 100<ul style="list-style-type: none">• On - Corresponding LAN port is using 100Base-TX.• Off - Corresponding LAN port connection is using 10Base-T, or no active connection.
WAN LED	On - Connection to the Broadband Modem attached to the WAN port is established. Off - No connection to the Broadband Modem. Flashing - Data is being transmitted or received via the WAN port.
WLAN LED	On - Wireless connection available; Wireless Access Point is ready for use. Off - No Wireless connection available. Flashing - Data is being transmitted or received via the Wireless interface of WRT-413. Data includes "network traffic" as well as user data.

Rear Panel




Figure 3: Rear Panel

Power (12V DC)

Connect the supplied power adapter here.

**LAN port (1-4)
10/100Base-TX**

Use standard LAN cables (with RJ45 connectors) to connect your PCs to these ports.

If required, any port can be connected to another hub/switch. Any LAN port will automatically function as an "Uplink" port when necessary.

**WAN port
(10/100Base-TX)**

Connect the xDSL or Cable Modem here. If your modem came with a cable, use the supplied cable. Otherwise, use a standard LAN cable.

Reset Button

This button has two (2) functions:

- **Reboot.** When pressed and released, the WRT-413 will reboot.
- **Clear All Data.** This button can also be used to clear ALL data and restore ALL settings to the factory default values.

To Clear All Data and restore to factory default:

1. Power Off.
2. Hold the Reset Button down while you Power On.
3. Keep holding the Reset Button for a few seconds, until the RED LED has flashed TWICE.
4. Release the Reset Button. The WRT-413 is now using the factory default values.

Chapter 2

Installation

2

This Chapter covers the physical installation of the WRT-413.

Requirements

- Network cables connection. Use standard 10/100Base-TX network cables (UTP) with RJ45 connectors.
- TCP/IP protocol must be installed on all PCs.
- For Internet Access, an Internet Access account from ISP and either of a xDSL or Cable modem (for WAN port usage)
- To use the Wireless Access Point, all Wireless devices must be compliant with the IEEE802.11b or IEEE802.11g specifications.

Procedure




Figure 4: Installation Diagram

1. Choose an Installation Site

Select a suitable place on the network to install the WRT-413.
Ensure the WRT-413 and the xDSL/Cable modem are powered OFF.



For best Wireless reception and performance, the WRT-413 should be positioned in a central location with minimum obstructions between the WRT-413 and the PCs.

Also, if using multiple Access Points, adjacent Access Points should use different Channels.

2. Connect LAN Cables

Use standard LAN cables to connect PCs to the LAN ports on the WRT-413. Both 10Base-T and 100Base-TX connections can be used simultaneously.

If required, connect any LAN port to a normal port on another Hub/Switch, using a standard LAN cable. The LAN ports on the WRT-413 will automatically function as an "Uplink" port when required.

3. Connect WAN Cable

Connect the xDSL or Cable modem to the WAN port on the WRT-413. Use the cable supplied with your xDSL/Cable modem. If no cable was supplied, please use a standard cable.

4. Power Up

- Power on the Cable or xDSL modem.
- Power on WRT-413. Use only the provided power adapter to connect. Using a different one may cause WRT-413 hardware damage

5. Check the LEDs

- The **Power** LED should be ON.
- The **Status** LED should flash, then turn Off. If it stays on, there is a hardware error.
- For each LAN (PC) connection, the LAN **LNK/ACT** LED should be ON (when the connected PC is ON.)
- The **WAN** LED should be ON.
- The **WLAN** LED should be ON

For more information, refer to [Front-mounted LEDs](#) in Chapter 1.

Chapter 3

Setup



This Chapter provides Setup details of WRT-413.

Overview

This chapter describes the setup procedure for:

- Internet Access
- LAN configuration
- Wireless setup
- Assigning a Password to protect the configuration data.

PCs on your local LAN may also require configuration. For details, see **Chapter 4 - PC Configuration**.

Other configuration may also be required, depending on the features and functions of the WRT-413 you wish to use. Refer to the table below to locate detailed instructions for the required functions.

To Do this:	Refer to:
Configure PCs on your LAN.	Chapter 4: PC Configuration
Check WRT-413 operation and Status.	Chapter 5: Operation and Status
Use any of the following Advanced features: <ul style="list-style-type: none">• Access Control• Dynamic DNS• Advanced Internet (Special Applications, DMZ, URL Filter)• Virtual Servers (Port Forwarding)• WAN Port Setup	Chapter 6: Advanced Features
Use any of the following Administration Configuration settings or features: <ul style="list-style-type: none">• Config File download/upload• Logs• Network Diagnostics (Ping, DNS Lookup)• Options (Backup DNS, TFTP, UPnP, Firewall)• PC Database• Remote Management• Routing (RIP and static Routing)• Security settings• Firmware Upgrade	Chapter 7 Advanced Administration

Configuration Program

The WRT-413 contains an HTTP server. This enables you to connect to it, and configure it, using your Web Browser that has support **JavaScript**.

The configuration program has been tested on the following browsers:

- Netscape V4.08 or later
- Internet Explorer V4 or later

Preparation

Before attempting to configure the WRT-413, please ensure that:

- Your PC can establish a physical connection to the WRT-413. The PC and the WRT-413 must be directly connected (using the LAN port on the WRT-413) or on the same LAN segment.
- The WRT-413 must be installed and powered ON.
- If the WRT-413's default IP address (192.168.0.1) is already used by another device, the other device must be turned OFF until the WRT-413 is allocated a new IP Address during configuration.

Using UPnP

If your Windows system supports UPnP, an icon for the WRT-413 will appear in the system tray, notifying you that a new network device has been found, and offering to create a new desktop shortcut to the newly-discovered device.

- Unless you intend to change the IP Address of the WRT-413, you can accept the desktop shortcut.
- Whether you accept the desktop shortcut or not, you can always find UPnP devices in *My Network Places* (previously called *Network Neighborhood*).
- Double - click the icon for the WRT-413 (either on the Desktop, or in *My Network Places*) to start the configuration. Refer to the following section [Setup Wizard](#) for details of the initial configuration process.

Using your Web Browser

To establish a connection from your PC to the WRT-413:

1. After installing the WRT-413 in your LAN.
2. Set your PC as a DHCP client and start. If your PC is already running, restart it.
3. Start your WEB browser.
4. In the **Address** field, enter "HTTP://" and the IP Address of the WRT-413, as in this example, which uses the WRT-413's default IP Address:

HTTP://192.168.0.1

The default password is blank, so your will not be prompted for a password. However, you should assign a password to your WRT-413. Please refer to the [Password](#) section later in this chapter for details.

If you can't connect WRT-413 configure screen

If the WRT-413 does not respond, check the following:

- The WRT-413 is properly installed, LAN connection is OK, and it is powered ON. You can test the connection by using the "Ping" command:
 - Open the MS-DOS window or command prompt window.
 - Enter the command:
`ping 192.168.0.1`
If no response is received, either the connection is not working, or your PC's IP address is not compatible with the WRT-413's IP Address. (See next item.)
- If your PC is using a fixed IP Address, its IP Address must be within the range 192.168.0.2 to 192.168.0.254 to be compatible with the WRT-413's default IP Address of 192.168.0.1. Also, the **Network Mask** must be set to 255.255.255.0. See **Chapter 4 - PC Configuration** for details on checking your PC's TCP/IP settings.
- Ensure that your PC and the WRT-413 are in the same network segment. (If you don't have a router, this must be the case.)
- Ensure you are using the wired LAN interface. The Wireless interface can only be used if its configuration matches your PC's wireless settings.

Setup Wizard

The first time you connect to the WRT-413, the Setup Wizard will run automatically. (The Setup Wizard will also run if the WRT-413's default settings are restored.)

1. Step through the Wizard until finished.
 - You need to know the type of Internet connection service used by your ISP. Check the data supplied by your ISP.
 - The common connection types are explained in the tables below.
2. On the final screen of the Wizard, run the test and check that an Internet connection can be established.
3. If the connection test fails:
 - Check your settings, Cable/xDSL modem status and all physical connections.
 - Check that you have entered all data correctly, as ISP provided.
 - If using a Cable modem, your ISP may have recorded the MAC address of your PC. Run the Wizard, and on the **Cable Modem** screen, use the "Clone MAC address" button to copy the MAC address from your PC to the WRT-413.

Common Connection Types

Cable Modems

Type	Details	ISP Data required
Dynamic IP Address	Your IP Address is allocated automatically, when you connect to you ISP.	Usually, none. However, some ISP's may require you to use a particular Hostname, Domain name, or MAC (physical) address.
Static (Fixed) IP Address	Your ISP gives a permanent IP Address to you.	IP Address allocated to you. Some ISP's may also require you to use a particular Hostname, Domain name, or MAC (physical) address.

xDSL Modems

Type	Details	ISP Data required
Dynamic IP Address	Your IP Address is allocated automatically, when you connect to you ISP.	None.
Static (Fixed) IP Address	Your ISP allocates a permanent IP Address to you.	IP Address allocated to you.
PPPoE	You connect to the ISP only when required. The IP address is usually allocated automatically.	User name and password.
PPTP	PPTP is mainly used in Europe. You connect to the ISP only when required. The IP address is usually allocated automatically, but may be Static (Fixed).	<ul style="list-style-type: none">• Server IP Address.• User name and password.• IP Address allocated to you, if Static (Fixed).

Other Modems (e.g. Broadband Wireless)

Type	Details	ISP Data required
Dynamic IP Address	Your IP Address is allocated automatically, when you connect to you ISP.	None.
Static (Fixed) IP Address	Your ISP allocates a permanent IP Address to you.	IP Address allocated to you.

Big Pond (Australia)

For this connection method, the following data is required:

- User Name
- Password
- Big Pond Server IP address

SingTel RAS

For this connection method, the following data is required:

- User Name
- Password
- RAS Plan

Home Screen

After finishing the Setup Wizard, you will see the **Home** screen. When you connect in future, you will see this screen when you connect. An example screen is shown below.



Figure 5: Home Screen

Navigation & Data Input

- Use the menu bar on the left of the screen, and the "Back" button on your Browser, for navigation.
- Changing to another screen without clicking "Save" does NOT save any changes you may have made. You must "Save" before changing screens or your data will be ignored.



Note!

On each screen, clicking the "Help" button will display help for that screen.

From any help screen, you can access the list of all help index.

LAN

Click the *LAN* option on the main menu to reach the LAN configuration. An example screen is shown below.

The screenshot shows the LAN configuration interface. It features a blue sidebar on the left with the text 'TCP/IP'. The main configuration area contains several input fields: 'IP Address' (192.168.0.1), 'Subnet Mask' (255.255.255.0), a checked 'DHCP Server' checkbox, 'Start IP Address' (ending in 2), and 'Finish IP Address' (ending in 51). At the bottom right, there are three buttons: 'Save', 'Cancel', and 'Help'.

Figure 6: LAN Screen

Parameters

TCP/IP	
IP Address	IP address for the WRT-413, as seen from the local LAN. Use the default value unless the address is already in use or your LAN is using a different IP address range. In the latter case, enter an unused IP Address from within the range used by your LAN.
Subnet Mask	The default value 255.255.255.0 is standard for small (class "C") networks. For other networks, use the Subnet Mask for the LAN segment to which the WRT-413 is attached (the same value as the PCs on that LAN segment).
DHCP Server	<ul style="list-style-type: none">• If Enabled, the WRT-413 will allocate IP Addresses to PCs (DHCP clients) on your LAN when they start up. The default (and recommended) value is Enabled.• If you have already a DHCP Server, this setting must be “Disabled”, and the existing DHCP server must be re-configured to treat the WRT-413 as the default Gateway. See the following section for further details.• The Start IP Address and Finish IP Address fields set the values used by the DHCP server when allocating IP Addresses to DHCP clients. This range also determines the number of DHCP clients supported. See the following section for further details on using DHCP.
Buttons	
Save	Save the data on screen.
Cancel	The "Cancel" button will discard any data you have entered and reload the file from the WRT-413.

DHCP

What DHCP Does

A DHCP (Dynamic Host Configuration Protocol) **Server** allocates a valid IP address to a DHCP **Client** (PC or device) upon request.

- The client request is made when the client device starts up.
- The DHCP Server provides the **Gateway** and **DNS** IP addresses to the client, as well as allocating an IP Address.
- The WRT-413 can act as a **DHCP server**.
- Windows 95/98/Me and other non-Server versions Windows OS will act as a DHCP **client**. This is the default Windows setting for the TCP/IP network protocol. However, Windows uses the term **Obtain an IP Address automatically** instead of "DHCP Client".
- You can NOT have two (2) or more DHCP Servers on the same LAN segment. In one LAN, only one DHCP Server can exist to assign IP address to the clients.

Using the WRT-413's DHCP Server

The DHCP Server settings are on the **LAN** option. In this option, you can:

- Enable or Disable the WRT-413's **DHCP Server** function.
- Set the range of IP Addresses that will allocate to clients by this DHCP Server.



You can assign Fixed IP Addresses to some devices while DHCP Server enable, please make sure the Fixed IP addresses are NOT within the IP range which used by the DHCP Server.

Using another DHCP Server

If you wish to use another DHCP Server, rather than the WRT-413's, the following procedure is required.

1. Disable the DHCP Server fn the WRT-413. This setting is on the LAN screen.
2. Configure the DHCP Server to provide the WRT-413's IP Address as the **Default Gateway** to the clients to access Internet.

To Configure your PCs to work with DHCP Server

The default setting under Windows TCP/IP network is a DHCP client. Please check **Chapter 4 - Client Configuration** for the procedure to check these settings.

Wireless

Click the **Wireless** option on the main menu to configure the Wireless settings. A configuration screen will show below.

Figure 7: Wireless Screen

Parameters

Identification	
Client name	It shows the WRT-413 name..
Region	Select your region from the drop-down list. This field displays the region of operation for the wireless interface is intended. If your country or region is not listed, please check with your local government agency for more information on which channels you are allowed to use, and select a region which compatible with those channels. (The channel number will changed according to the selected region.)
SSID	SSID is used by all wireless devices within the ESS or extended wireless LAN. The SSID value must be the same on all clients and Access points in this WLAN.
Options	
Mode	Select the desired mode: <ul style="list-style-type: none"> g & b - Both 802.11.g and 802.11b wireless clients will be able to connect to WRT-413. g only - Only 802.11b connections are available. b only - Only 802.11b connections are available. 802.11g clients will only be able to use the WRT-413 if they are fully backward-compatible with the 802.11b standard.

Channel No.	<p>This option determines which operating channel will be used to the clients. The channel number will changed depended on different region.</p> <p>Select the desired channel. If there is adjacent Access Points, they should use different channels to avoid interference.</p>
Broadcast SSID	<p>When enabled, the SSID will be broadcasted to all wireless clients. The clients which have no SSID (or a "null" value) can then adopt the WRT-413's SSID to connect to it.</p>
Wireless Security	<ul style="list-style-type: none"> • Current Setting - This will display "Enabled" or "Disabled" • Configure - Click this button to access the Wireless Security sub-screen and configure encryption settings.
Access Point	
Enable Access Point	<ul style="list-style-type: none"> • Select Enable. Wireless clients will be able to locate and use this Access Point. If this option is not be selected, WRT-413 wireless interface will disabled. • The WLAN LED on the front panel will remain OFF if the Wireless interface is disabled.
Allow LAN access by:	<ul style="list-style-type: none"> • All Wireless Clients - All wireless clients can access to your LAN via WRT-413. • Selected Wireless clients only - Only selected wireless clients can access to your LAN. To select the required wireless clients, click the "Select Clients" button. You can find all the wireless clients in the list and select which clients are allow to access to your LAN.
Allow Internet access by:	<ul style="list-style-type: none"> • All Wireless Clients - All wireless clients can access to Internet via WRT-413. • Selected Wireless clients only - Only selected wireless clients can access to Internet. To select the required wireless clients, click the "Select Clients" button. You can find all the wireless clients in the list and select which clients are allow to access to Internet service.
Buttons	
Configure	Click this button to configure the Wireless Security as next page.
Select Stations	Click this button to select the required PCs.
Save	Save current settings.
Cancel	The "Cancel" button will discard all the settings to the configuration that you have entered since the last "Save" operation.

Wireless – Wireless Security

After click the “Configure” button of Wireless option, you can see the screen as below and configure the settings for wireless data encryption.

Figure 8: WEP Screen

Parameters

Security System	<ul style="list-style-type: none"> • Disabled – It is the default setting. Data will NOT encrypted before being transmitted. • WEP – WEP is an authentication algorithm, which protects authorized Wireless LAN users against eavesdropping. • WPA-PSK – It is an extra-strong encryption where encryption keys are automatically changed (called Rekeying) and authenticated between devices after a specified period of time, or after a specified number of packets has been transmitted. When you select this mode, please check the screen below to configure. It's configure screen is different to WEP mode.
Authentication Type	Normally, this should be left at the default value of “Automatic”. If changed to “Open System” or “Shared Key”, ensure that your wireless clients have set with the same setting.
Key Size	<ul style="list-style-type: none"> • 64-bit – Data will be encrypted with the Default Key before transmitted. For 64-bit Encryption, the Default Key size is 5 chars (ASCII) or 10 chars in HEX. • 128-bit – Data will be encrypted, using the default key, before being transmitted. For 128-bit Encryption, the Default Key size is 13 chars (ASCII) or 26 chars in HEX
Key Input	Select "Hex" or "ASCII", depending on your input method.
Key 1 ~ 4	There are 4 keys available, please select one of them to use.

Key Value	Enter the Key Value you wish to use. Please ensure you have enter correct number for the key values with different Key Length and coding (Hex or ASCII) as 64bit (10 Hex digit / 5 ASCII), 128bit (26 Hex digit / 13 ASCII).
Passphrase	If desired, you can generate a key from a phrase, instead of entering the key value directly. Enter the desired phrase, and click the "Generate " button.

The screenshot shows a window titled "Wireless Security". Inside the window, the "Security System" is set to "WPA - PSK". Below this, there is a text input field for "PSK :". Underneath the PSK field, "Key Lifetime" is set to "3600 (secs)". Below that, "Encryption" is set to "TKIP". At the bottom of the window, there are four buttons: "Save", "Cancel", "Help", and "Close".


Figure 9-1: WPA-PSK Screen

Parameters

PSK	You may enter a hard-to-guess passphrase (between 8 and 63 characters) to be your PSK (Pre Shared Key).
Key Lifetime	In default, it is 3600 Seconds. You can change the time to you want (from 0 to 9999).
Encryption	TKIP can change the encryption key frequently to enhance the wireless LAN security.

Password


The password screen allows you to assign a password to the WRT-413.



The screenshot shows a web-based configuration interface for the WRT-413. It has a dark blue header with the word "Password" in yellow. Below the header is a sidebar with a blue background and the word "Password" in white. The main content area has a light blue background and contains the following text: "The password protects the configuration data. Once set (recommended), you will be prompted for the password when you connect." Below this text are two input fields: "New password:" and "Verify password:". At the bottom right of the main content area are three buttons: "Save", "Cancel", and "Help".

Figure 10: Password Screen

Once you have assigned a password, WRT-413 will be prompted you the dialog box below for enter password when you login to the configure screen. (If no password has been set, this dialog will not appear.)



The screenshot shows a Windows-style dialog box titled "Enter Network Password". It has a blue title bar with a question mark icon and a close button. The main area has a gray background and contains the following text: "Please type your user name and password." Below this text are two input fields: "User Name" and "Password". Above the "User Name" field is a label "Site:" with the value "192.168.0.1". Above the "Password" field is a label "Realm" with the value "NeedPassword". Below the input fields is a checkbox labeled "Save this password in your password list". At the bottom right of the dialog box are two buttons: "OK" and "Cancel".

Figure 11: Password Dialog

- Leave the "User Name" blank.
- Enter the password as you have set before.

Chapter 4

PC Configuration



This Chapter details the PC Configuration required on the local ("Internal") LAN.

Overview

For each PC, the following may need to be configured:

- TCP/IP network settings
- Internet Access configuration
- Wireless configuration

Windows Clients

This section describes how to configure Windows clients for Internet access via the WRT-413.

The first step is to check the PC's TCP/IP settings.

WRT-413 uses TCP/IP protocol for all functions, so it is essential that the TCP/IP protocol be installed and configured on each PC.

TCP/IP Settings - Overview

If using default settings of WRT-413 and Windows TCP/IP configuration, no changes will be needed.

- By default, the WRT-413 will act as a DHCP Server, automatically providing a suitable IP Address (and related information) to each PC when the PC boots.
- For Windows, the default TCP/IP setting is to act as a DHCP client.

If using a Fixed IP address, the following changes are required:

- The *Gateway* must be set to the IP address of the WRT-413
- The *DNS* should be set to the address provided by your ISP.



If your LAN has a Router, the LAN Administrator must to re-configure the Router. Please refer to *Chapter 8 - Advanced Setup* for details.

Checking TCP/IP Settings - Windows 9x/Me:

1. Select *Control Panel - Network*. You should see a screen as below:




Figure 12: Network Configuration

2. Select the *TCP/IP* protocol for your network card.
3. Click on the *Properties* button. You should then see a screen as below.




Figure 13: IP Address (Win 95)

Ensure your TCP/IP settings are correct, as follows:

Using DHCP

To use DHCP, select "*Obtain an IP Address automatically*". This is the default in Windows. **Using this setting is recommended.** By default, the WRT-413 will act as a DHCP Server.

Restart your PC and ensure it obtains an IP Address from the WRT-413.

Using "Specify an IP Address"

If your PC is already configured, check with your network administrator before configure the following settings:

- On the *Gateway* tab, enter the WRT-413's IP address in the *New Gateway* field and click *Add*. Your network administrator can advise you of the IP address they had assigned to the WRT-413.




Figure 14: Gateway Tab (Win 95/98)

- On the **DNS Configuration** tab, ensure **Enable DNS** is selected. If the **DNS Server Search Order** list is empty, enter the DNS address provided by your ISP, then click **Add**.




Figure 15: DNS Tab (Win 95/98)

Checking TCP/IP Settings - Windows NT4.0

1. Select *Control Panel - Network*, and, on the *Protocols* tab, select the TCP/IP protocol, as shown below.




Figure 16: Windows NT4.0 - TCP/IP

2. Click the "*Properties...*" button, you will see a screen as below.




Figure 17: Windows NT4.0 - IP Address

3. Select the network adapter you are using.
4. Select “*Obtain an IP address from a DHCP Server*” or “*Specify an IP Address*” as explained below.

Obtain an IP address from a DHCP Server

To use DHCP, select “*Obtain an IP Address automatically* “. This is the default in Windows. **Using this setting is recommended.** By default, the WRT-413 will act as a DHCP Server.

Restart your PC and ensure it has obtain an IP Address from your WRT-413.

Specify an IP Address

If your PC is already configured, check with your network administrator before configure the following settings.

1. The *Default Gateway* is set to the IP address of the WRT-413.
 - Click the *Advanced* button on the screen above.
 - On the following screen, click the *Add* button in the *Gateways* panel, and enter the WRT-413's IP address, as shown in Figure 18 below.
 - If necessary, use the *Up* button to make the WRT-413 to the first entry in the gateway list.




Figure 18 - Windows NT4.0 - Add Gateway

2. The DNS should be set to the address provided by your ISP, as follows:
 - Click the DNS tab.
 - In the DNS screen below, click the **Add** button (under **DNS Service Search Order**), and enter the DNS provided by your ISP.




Figure 19: Windows NT4.0 - DNS

Checking TCP/IP Settings - Windows 2000:

1. Select *Control Panel - Network and Dial-up Connection*.
2. Right - click the *Local Area Connection* icon and select *Properties*. You should see a screen as below:




Figure 20: Network Configuration (Win 2000)

3. Select the "*Internet protocol (TCP/IP)*".
4. Click on the *Properties* button. You should then see a screen as below.




Figure 21: TCP/IP Properties (Win 2000)

5. Ensure your TCP/IP settings are correct, as described below.

Using DHCP

To use DHCP, select “*Obtain an IP Address automatically* “. This is the default in Windows. **Using this setting is recommended.** By default, the WRT-413 will act as a DHCP Server.

Restart your PC and ensure it obtains an IP Address from the WRT-413.

Using a fixed IP Address ("Use the following IP Address")

If your PC is already configured, check with your network administrator before configure the following settings.

- Enter the WRT-413's IP address in the **Default gateway** field and click **OK**. (Your network administrator can advise you of the IP Address they assigned to the WRT-413.)
- If the **DNS Server** fields are empty, select **Use the following DNS server addresses**, and enter the DNS address provided by your ISP, then click **OK**.

Checking TCP/IP Settings - Windows XP

1. Select *Control Panel - Network Connection*.
2. Right click the *Local Area Connection* and choose *Properties*. You should see a screen as below.




Figure 22: Network Configuration (Windows XP)

3. Select the *"Internet Protocol TCP/IP"*.
4. Click on the *Properties* button. You should then see a screen as below.




Figure 23: TCP/IP Properties (Windows XP)

5. Ensure your TCP/IP settings are correct.

Using DHCP

To use DHCP, select "*Obtain an IP Address automatically*". This is default in Windows. **Using this setting is recommended.** By default, the WRT-413 will act as a DHCP Server.

Restart your PC to ensure it obtains an IP Address from the WRT-413.

Using a fixed IP Address ("Use the following IP Address")

If your PC is already configured, check with your network administrator before configure the following settings.

- In the *Default gateway* field, enter the WRT-413's IP address and click **OK**. Your network administrator can advise you of the IP address they assigned to the WRT-413.
- If the *DNS Server* fields are empty, select *Use the following DNS server addresses*, and enter the DNS address provided by your ISP, then click **OK**.

Internet Access

To configure your PCs to use the WRT-413 for Internet access:

- Ensure that the xDSL modem, Cable modem, or other permanent connection is functional.
- Use the following procedure to configure your Browser to access the Internet via the LAN, rather than by a Dial-up connection.

For Windows 9x/Me/2000

1. Select *Start Menu - Settings - Control Panel - Internet Options*.
2. Select the *Connection* tab, and click the *Setup* button.
3. Select "*I want to set up my Internet connection manually or I want to connect through a local area network (LAN)*" and click *Next*.
4. Select "*I connect through a local area network (LAN)*" and click *Next*.
5. Ensure all of the boxes on the following Local area network Internet Configuration screen are **unchecked**.
6. Check the option "*No*" when prompted the message "Do you want to set up an Internet mail account now?".
7. Click *Finish* to close the Internet Connection Wizard.
8. Setup is now completed.

For Windows XP

1. Select *Start Menu - Control Panel - Network and Internet Connections*.
2. Select *Set up or change your Internet Connection*.
3. Select the *Connection* tab, and click the *Setup* button.
4. Cancel the pop-up "Location Information" screen.
5. Click *Next* on the "New Connection Wizard" screen.
6. Select "Connect to the Internet" and click *Next*.
7. Select "Set up my connection manually" and click *Next*.
8. Check "Connect using a broadband connection that is always on" and click *Next*.
9. Click *Finish* to close the New Connection Wizard.
10. Setup is now completed.

Accessing AOL

To access AOL (America On Line) through the WRT-413, the *AOL for Windows* software must be configured to use TCP/IP network access, rather than a dial-up connection. The configuration process is as follows:

- Start the *AOL for Windows* communication software. Ensure that it is Version 2.5, 3.0 or later. This procedure will not work with earlier versions.
- Click the *Setup* button.
- Select *Create Location*, and change the location name from "New Locality" to "WRT-413".
- Click *Edit Location*. Select *TCP/IP* for the *Network* field. (Leave the *Phone Number* blank.)
- Click *Save*, then *OK*.
Configuration is now complete.
- Before clicking "Sign On", always ensure that you are using the "WRT-413" location.

Macintosh Clients

From your Macintosh, you can access the Internet via the WRT-413. The procedure is as follows.

1. Open the TCP/IP Control Panel.
2. Select **Ethernet** from the **Connect via** pop-up menu.
3. Select **Using DHCP Server** from the **Configure** pop-up menu. The DHCP Client ID field can be left blank.
4. Close the TCP/IP panel, saving your settings.

Note:

If using manually assigned IP addresses instead of DHCP, the required changes are:

- Set the **Router Address** field to the WRT-413's IP Address.
- Ensure your DNS settings are correct.

Linux Clients

To access the Internet via the WRT-413, it is only necessary to set the WRT-413 as the "Gateway".

Ensure you are logged in as "root" before attempting any changes.

Fixed IP Address

By default, most Unix installations use a fixed IP Address. If you wish to continue using a fixed IP Address, make the following changes to your configuration.

- Set your "Default Gateway" to the IP Address of the WRT-413.
- Ensure your DNS (Name server) settings are correct.

To act as a DHCP Client (recommended)

The procedure below may vary according to your version of Linux and X -windows shell.

1. Start your X Windows client.
2. Select **Control Panel - Network**
3. Select the "Interface" entry for your Network card. Normally, this will be called "eth0".
4. Click the **Edit** button, set the "protocol" to "DHCP", and save this data.
5. To apply your changes
 - Use the "Deactivate" and "Activate" buttons, if available.
 - OR, restart your system.

Other Unix Systems

To access the Internet via the WRT-413:

- Ensure the "Gateway" field for your network card is set to the IP Address of the WRT-413.
- Ensure your DNS (Name Server) settings are correct.

Wireless Client Configuration

This section applies to all Wireless clients wishing to use the WRT-413's Access Point, regardless of the operating system which is used on the client.

To use the Wireless Access Point in the WRT-413, each Wireless Client must have compatible settings, as follows:

Mode	The mode must be set to <i>Infrastructure</i> .
SSID (ESSID)	This must match the value used on the WRT-413. The default value is default Note! The SSID is case sensitive.
WEP	By default, WEP on the WRT-413 is disabled . <ul style="list-style-type: none">• If WEP remains disabled on the WRT-413, all clients must have WEP disabled.• If WEP is enabled on the WRT-413, each client must use the same settings as the WRT-413.

Note:

By default, the WRT-413 will allow both 802.11b and 802.11g connections.

Chapter 5

Operation and Status



This Chapter details the operation of the WRT-413 and the status screens.

Operation

Once both the WRT-413 and the PCs are configured, operation is automatic.

However, there are some situations where additional Internet configuration may be required:

- If using Internet-based **Communication Applications**, it may be necessary to specify which PC receives an incoming connection. Refer to **Chapter 6 - Advanced Features** for further details.
- Applications which use non-standard connections or port numbers may be blocked by the WRT-413's built-in firewall. You can define such applications as **Special Applications** to allow them to function normally. Refer to **Chapter 6 - Advanced Features** for further details.
- Some non-standard applications may require use of the **DMZ** feature. Refer to **Chapter 6 - Advanced Features** for further details.

Status Screen

Use the **Status** link on the main menu to view this screen.

The screenshot shows the 'Status' screen with a dark blue header. On the left is a vertical menu with 'Internet', 'LAN', and 'System' in white text. The main area has a light blue background and displays the following information:

Internet	Connection Method:	Direct
	Broadband Modem :	No Connection
	Internet Connection:	Idle
	Internet IP Address:	192.168.99.32
Connection Details		
LAN	IP Address:	192.168.0.1
	Network Mask:	255.255.255.0
	DHCP Server:	ON
System	Device Name:	PLEEDAC4
	Firmware Version:	Version 1.0 Release 01
System Data		
Restart Refresh Screen Help		

Figure 24: Status Screen

Data - Status Screen

Internet	
Connection Method	This indicates the current connection method, as set in the <i>Setup</i>

	<i>Wizard</i> or <i>WAN Port</i> screen.
Broadband Modem	This shows the status of the connection from the WRT-413 to the Broadband Modem.
Internet Connection	<p>Current connection status:</p> <ul style="list-style-type: none"> • Active • Idle • Unknown • Failed <p>If there is an error, you can click the "Connection Details" button to find out more information.</p>
Internet IP Address	This IP Address is allocated by the ISP (Internet Service Provider). If there is no current connection, this will be blank or 0.0.0.0.
"Connection Details" Button	Click this button to open a sub-window and view a detailed description of the current connection. Depending on the type of connection, a "Connection Log" may also be available.
LAN	
IP Address	The IP Address of WRT-413 LAN interface.
Network Mask	The Network Mask (Subnet Mask) for the IP Address above.
DHCP Server	<p>This shows the status of the DHCP Server function - either "Enabled" or "Disabled".</p> <p>For additional information about the PCs on your LAN, and the IP addresses allocated to them, use the <i>PC Database</i> option of the <i>Administration</i> menu.</p>
System	
Device Name	This displays the current name of the WRT-413.
Firmware Version	The current version of the firmware installed in the WRT-413.
Buttons	
Connection Details	Shows the details of the current Internet connection. The sub-screen displayed will depend on the connection method used. See the following sections for details of each sub-screen.
System Data	Display all system information in a sub-window.
Restart	Clicking this button will restart (reboot) the WRT-413. All existing connections though the WRT-413 will be terminated, but will usually re-connect automatically after restart.
Refresh Screen	Update the displayed data on screen.

Connection Status - PPPoE

If using PPPoE (PPP over Ethernet), a screen as below will be displayed when the "Connection Details" button is clicked.

Connection Status - PPPoE

Connection

Physical Address: 00-30-4f-ee-da-c5
IP Address:
Network Mask:
PPPoE Link Status: OFF

Connection Log

```
005: Reset physical connection
004: stop PPP
003: try to hang up
002: sub_wait:timeout
001: wait 100 msec "WAN start... "
000: stop PPP
```

Connect and Disconnect buttons should only be needed if the setting "Connect automatically, as required" is Disabled.

Figure 25: PPPoE Status Screen

Data - PPPoE Screen

Connection	
Physical Address	The hardware address of this device, as seen by remote devices on the Internet. (This is different to the hardware address seen by devices on the local LAN.)
IP Address	The IP Address of this device, as seen by Internet users. This address is allocated by your ISP (Internet Service Provider).
Network Mask	The Network Mask associated with the IP Address above.
PPPoE Link Status	<p>This indicates whether or not the connection is currently established.</p> <ul style="list-style-type: none"> If the connection does not exist, the "Connect" button can be used to establish a connection. If the connection currently exists, the "Disconnect" button can be used to break the connection.
Connection Log	
Connection Log	<ul style="list-style-type: none"> The Connection Log shows status messages relating to the existing connection. The most common messages are listed in the table below. The "Clear Log" button will restart the Log, while the Refresh button will update the messages shown on screen.
Buttons	
Connect	When the connection is not established, it will connect to your ISP

	after click this button.
Disconnect	If WRT-413 is connecting to your ISP, it will hang up the connection.
Clear Log	Delete all data of the Log. This will make it easier to read new messages.
Refresh	Update the data on screen.

Connection Log Messages

Message	Description
Connect on Demand	Connection attempt has been triggered by the "Connect automatically, as required" setting.
Manual connection	Connection attempt started by the "Connect" button.
Reset physical connection	Preparing line for connection attempt.
Connecting to remote server	Attempting to connect to the ISP's server.
Remote Server located	ISP's Server has responded to connection attempt.
Start PPP	Attempting to login to ISP's Server and establish a PPP connection.
PPP up successfully	Able to login to ISP's Server and establish a PPP connection.
Idle time-out reached	The connection has been idle for the time period specified in the "Idle Time-out" field. The connection will now be terminated.
Disconnecting	The current connection is being terminated, due to either the "Idle Time-out" above, or "Disconnect" button being clicked.
Error: Remote Server not found	ISP's Server did not respond. This could be a Server problem, or a problem with the link to the Server.
Error: PPP Connection failed	Unable to establish a PPP connection with the ISP's Server. This could be a login problem (name or password) or a Server problem.
Error: Connection to Server lost	The existing connection has been lost. This could be caused by a power failure, a link failure, or Server failure.
Error: Invalid or unknown packet type	The data received from the ISP's Server could not be processed. This could be caused by data corruption (from a bad link), or the Server using a protocol which is not supported by this device.

Connection Status - PPTP

If using PPTP (Peer-to-Peer Tunneling Protocol), a screen as below will be displayed when the "Connection Details" button is clicked.

Connection Status - PPTP

Connection

Physical Address: 00-30-4f-ee-da-c5
 IP Address:
 Connection Status OFF

Connection Log

```
005:Reset physical connection
004:stop PPP
003:try to hang up
002:sub_wait:timeout
001:wait 100 msec "WAN start... "
000:stop PPP
```

Clear Log

Connect and Disconnect buttons should only be needed if the setting
 "Connect automatically, as required" is Disabled.

Connect Disconnect

Refresh Help Close

Figure 26: PPTP Status Screen

Data - PPTP Screen

Connection	
Physical Address	The hardware address of this device, as seen by remote devices on the Internet. (This is different to the hardware address seen by devices on the local LAN.)
IP Address	The IP Address of this device, as seen by Internet users. This address is allocated by your ISP (Internet Service Provider).
PPTP Status	This indicates whether or not the connection is currently established. <ul style="list-style-type: none"> If the connection does not exist, the "Connect" button can be used to establish a connection. If the connection currently exists, the "Disconnect" button can be used to break the connection.
Connection Log	
Connection Log	<ul style="list-style-type: none"> The Connection Log shows status messages relating to the existing connection. The "Clear Log" button will restart the Log, while the Refresh button will update the messages shown on screen.
Buttons	
Connect	When the connection is not established, it will connect to your ISP

	after click this button.
Disconnect	If WRT-413 is connecting to your ISP, it will hang up the connection.
Clear Log	Delete all data currently in the Log. This will make it easier to read new messages.
Refresh	Update the data on screen.

Connection Status - L2TP

If using L2TP, a screen as below will be displayed when the "Connection Details" button is clicked.

Figure 27: L2TP Status Screen

Data - L2TP Screen

Connection	
Physical Address	The hardware address of this device, as seen by remote devices on the Internet. (This is different to the hardware address seen by devices on the local LAN.)
IP Address	The IP Address of this device, as seen by Internet users. This address is allocated by your ISP (Internet Service Provider).
Connection Status	<p>This indicates whether or not the connection is currently established.</p> <ul style="list-style-type: none"> • If the connection does not exist, the "Connect" button can be used to establish a connection. • If the connection currently exists, the "Disconnect" button can be used to break the connection.

Connection Log	
Connection Log	<ul style="list-style-type: none"> The Connection Log shows status messages relating to the existing connection. The "Clear Log" button will restart the Log, while the Refresh button will update the messages shown on screen.
Buttons	
Connect	When the connection is not established, it will connect to your ISP after click this button.
Disconnect	If WRT-413 is connecting to your ISP, it will hang up the connection.
Clear Log	Delete all data currently in the Log. This will make it easier to read new messages.
Refresh	Update the data on screen.

Connection Status - Telstra Big Pond

If using Telstra Big Pond, a screen as below will be displayed when the "Connection Details" button is clicked.

Connection Status - Telstra Big Pond

Connection

Physical Address: 00-30-4f-ee-da-c5
IP Address:
Connection Status: Not logged in

Connection Log

```
001:wait 100 msec "WAN start... "
000:stop PPP
```

Clear Log

Connect and Disconnect buttons should only be needed if the setting "Connect automatically, as required" is Disabled.

Connect Disconnect Refresh Help Close

Figure 28: Telstra Big Pond Status Screen

Data - Big Pond Screen

Connection	
Physical Address	The hardware address of this device, as seen by remote devices. (This is different to the hardware address seen by devices on the local LAN.)

IP Address	The IP Address of this device, as seen by Internet users. This address is allocated by your ISP (Internet Service Provider).
Connection Status	<p>This indicates whether or not the connection is currently established.</p> <ul style="list-style-type: none"> • If the connection does not exist, the "Connect" button can be used to establish a connection. • If the connection currently exists, the "Disconnect" button can be used to break the connection. • Normally, it is not necessary to use the Connect and Disconnect buttons unless the setting "Connect automatically, as required" is disabled.
Connection Log	
Connection Log	<ul style="list-style-type: none"> • The Connection Log shows status messages relating to the existing connection. • The Clear Log button will restart the Log, while the Refresh button will update the messages shown on screen.
Buttons	
Connect	When the connection is not established, it will connect to your ISP after click this button.
Disconnect	If WRT-413 is connecting to your ISP, it will hang up the connection.
Clear Log	Delete all data currently in the Log. This will make it easier to read new messages.
Refresh	Update the data on screen.

Connection Details - SingTel RAS

If using the SingTel RAS access method, a screen as below will be displayed when the "Connection Details" button is clicked.

Connection Details - RAS

Internet

RAS Plan 512K Ethernet
Physical Address: 00304feedac5
IP Address:
Network Mask:
Default Gateway:
DNS IP Address:
DHCP Client: ON
Lease obtained: 0 days,0 hrs, 0minutes
Remaining lease time: 0 days,0 hrs, 0minutes

Renew
Refresh

Help
Close

Figure 29: Connection Details - RAS

Data - RAS Screen

Internet	
RAS Plan	The RAS Plan which is currently used.
Physical Address	The hardware address of this device, as seen by remote devices on the Internet. (This is different to the hardware address seen by devices on the local LAN.)
IP Address	The IP Address of this device, as seen by Internet users. This address is allocated by your ISP (Internet Service Provider).
Network Mask	The Network Mask associated with the IP Address above.
Default Gateway	The IP Address of the remote Gateway or Router associated with the IP Address above.
DNS IP Address	The IP Address of the Domain Name Server which is currently used.
DHCP Client	<p>This will show "Enabled" or "Disabled", depending on whether or not this device is functioning as a DHCP client.</p> <p>If "Enabled" the "Remaining lease time" field indicates when the IP Address allocated by the DHCP Server will expire. The lease is automatically renewed on expiry; use the "Renew" button if you wish to manually renew the lease immediately.</p>
Buttons	
Release/Renew Button will display either "Release"	This button is only useful if the IP address shown above is allocated automatically on connection. (Dynamic IP address). If you have a Fixed (Static) IP address, this button has no effect.

or "Renew"	<ul style="list-style-type: none"> • If the ISP's DHCP Server has NOT allocated an IP Address for the WRT-413, this button will say "Renew". Clicking the "Renew" button will attempt to re-establish the connection and obtain an IP Address from the ISP's DHCP Server. • If an IP Address has been allocated to the WRT-413 (by the ISP's DHCP Server), this button will say "Release". Clicking the "Release" button will break the connection and release the IP Address.
Refresh	Update the data shown on screen.

Connection Details - Fixed/Dynamic IP Address

If your access method is "Direct" (no login), a screen as below will be displayed when the "Connection Details" button is clicked.

The screenshot shows a window titled "Connection Details" with a black header and yellow text. Below the header is a blue bar with the word "Internet" in white. The main area is white and contains the following text:

```
Physical Address: 00-30-4f-ee-da-c5
IP Address:      192.168.99.32
Network Mask:   255.255.255.0
Default Gateway: 192.168.99.254
DNS IP Address: 139.175.55.244
DHCP Client:    OFF
                Lease obtained:      n/a
                Remaining lease time: n/a
```

At the bottom right of the window are three buttons: "Refresh", "Help", and "Close".

Figure 30: Connection Details - Fixed/Dynamic IP Address

Data - Fixed/Dynamic IP address Screen

Internet	
Physical Address	The hardware address of this device, as seen by remote devices on the Internet. (This is different to the hardware address seen by devices on the local LAN.)
IP Address	The IP Address of this device, as seen by Internet users. This address is allocated by your ISP (Internet Service Provider).
Network Mask	The Network Mask associated with the IP Address above.
Default Gateway	The IP Address of the Gateway or Router associated with the IP Address above.
DNS IP Address	The IP Address of the Domain Name Server which is currently used.
DHCP Client	<p>This will show "Enabled" or "Disabled", depending on whether or not this device is functioning as a DHCP client.</p> <p>If "Enabled" the "Remaining lease time" field indicates when the IP Address allocated by the DHCP Server will expire. The lease is automatically renewed on expiry; use the "Renew" button if you wish to manually renew the lease immediately.</p>

Buttons	
Release/Renew	This button is only useful if the IP address shown above is allocated automatically on connection. (Dynamic IP address). If you have a Fixed (Static) IP address, this button has no effect.
Refresh	Update the data shown on screen.

Chapter 6

Advanced Features



This Chapter explains when and how to use the WRT-413's "Advanced" Features.

Overview

The following advanced features are provided.

- Access Control
- Dynamic DNS
- Advanced Internet
 - Communication Applications
 - Special Applications
 - Multi-DMZ
 - URL filter
- Virtual Servers
- WAN Port

Access Control

This feature is accessed by the *Access Control* link of the *Advanced* menu.

Overview

The Access Control feature allows administrators to restrict the level of Internet Access available to PCs on your LAN. With the default settings, everyone has unrestricted Internet access.

To use this feature:

1. Set the desired restrictions on the "Default" group. All PCs are in the "Default" group unless explicitly moved to another group.
2. Set the desired restrictions on the other groups ("Group 1", "Group 2", "Group 3" and "Group 4") as needed.
3. Assign PC to the groups as required.



Restrictions are imposed by blocking "Services" or types of connections. All common Services are pre-defined. If required, you can also define your own Services.

Access Control Screen

This screen allows you to set the clients to access to the Internet with different limitation.

Figure 31: Access Control Screen

Data - Access Control Screen

Group	
Group	Select the desired Group. The screen will update to display the settings for the selected Group. Groups are named "Default", "Group 1", "Group 2", "Group 3" and "Group 4", and cannot be re-named.
"Members" Button	<p>Click this button to add or remove members from the current Group.</p> <ul style="list-style-type: none"> • If the current group is "Default", then members can not be added or deleted. This group contains PCs not allocated to any other group. • To remove PCs from the Default Group, assign them to another Group. • To assign PCs to the Default Group, delete them from the Group they are currently in. <p>See the following section for details of the <i>Group Members</i> screen.</p>

Internet Access	
Restrictions	<p>Select the desired options for the current group:</p> <ul style="list-style-type: none"> • None - Nothing is blocked. Use this to create the least restrictive group. • Block all Internet access - All traffic via the WAN port is blocked. Use this to create the most restrictive group. • Block selected Services - You can select which Services are to block. Use this to gain fine control over the Internet access for a group.
Block by Schedule	If Internet access is being blocked, you can choose to apply the blocking only during scheduled times. (If access is not blocked, no Scheduling is possible, and this setting has no effect.)
Define Schedule Button	Clicking this will open a sub-window where you can define or modify the Schedule.
Services	This lists all defined Services. Select the Services you wish to block. To select multiple services, hold the CTRL key while selecting. (On the Macintosh, hold the SHIFT key rather than CTRL.)
Edit Service List Button	If you wish to define additional Services, or manage the Service list, click this button to open the "Services" screen.
Buttons	
Members	<p>Click this button to add or remove members from the current Group.</p> <p>If the current group is "Default", then members can not be added or deleted. This group contains PCs not allocated to any other group.</p> <p>See the following section for details of the <i>Group Members</i> screen.</p>
Define Schedule	Click this button to open a sub-window where you can define or modify the Schedule.
Edit Service List	If you wish to define additional Services, or manage the Service list, click this button to open the "Services" screen.
Save	Save the data on screen.
Cancel	Reverse any changes made since the last "Save".
View Log	Click this to open a sub-window where you can view the "Access Control" log. This log shows attempted Internet accesses which have been blocked by the Access Control feature.
Clear Log	Click this to clear and restart the "Access Control" log, making new entries easier to read.
Refresh	Update the data on screen.

Group Members Screen

This screen allows you to set the clients to different group. All the clients will be in the group “Default” when they are not in Group 1~4.




Figure 32: Group Members

Use this screen to add or remove members (PCs) from the current group.

- The "Del >>" button will remove the selected PC (in the *Members* list) from the current group.
- The "<< Add" button will add the selected PC (in the *Other PCs* list) to the current group.



Note!

PCs not assigned to any group will be in the "Default" group.
PCs deleted from any other Group will be added to the "Default" group.

Default Schedule Screen

This screen is displayed when the **Define Schedule** button on the **Access Control** screen is clicked.

- This schedule can be (optionally) applied to any Access Control Group.
- Blocking will be performed during the scheduled time (between the "Start" and "Finish" times.)
- Two (2) separate sessions or periods can be defined.
- Times must be entered using a 24 hr clock.
- If the time for a particular day is blank, no action will be performed.

Day	Session 1		Session 2	
	Start	Finish	Start	Finish
Monday	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Tuesday	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Wednesday	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Thursday	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Friday	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Saturday	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Sunday	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Buttons: Save, Cancel, Help, Close

Figure 33: Default Schedule Screen

Data - Default Schedule Screen

Day	Each day of the week can scheduled independently.
Session 1 Session 2	Two (2) separate sessions or periods can be defined. Session 2 can be left blank if not required.
Start Time	Enter the start using a 24 hr clock.
Finish Time	Enter the finish time using a 24 hr clock.

Services Screen

This screen allows you to add a new Service when you can not find the service in the Available Services list.

The screenshot shows a window titled "Services" with a black header. Inside, there are two main sections. The top section, "Available Services", contains a list box with the following items: Any(TCP), Any(UDP), AIM(TCP:5190), BGP(TCP:179), BOOTP_CLIENT(UDP:68), and BOOTP_SERVER(UDP:67). Below the list box is a "Delete" button. The bottom section, "Add New Service", contains a form with the following fields: "Name:" (text input), "Type:" (dropdown menu with "TCP" selected), "Start Port:" (text input with "(TCP or UDP)" to its right), "Finish Port:" (text input with "(TCP or UDP)" to its right), and "ICMP Type:" (text input with "(0..255)" to its right). Below the form are "Add" and "Cancel" buttons. At the bottom right of the window are "Help" and "Close" buttons.

Figure 34: Access Control - Services

Data - Services Screen

Available Services	
Available Services	This lists all the available services.
"Delete" button	Use this to delete any Service you have added. Pre-defined Services can not be deleted.
Add New Service	
Name	Enter a descriptive name to identify this service.
Type	Select the protocol (TCP, UDP, ICMP) used to the remote system or service.
Start Port	For TCP and UDP Services, enter the beginning of the range of port numbers used by the service. If the service uses a single port number, enter it in both the "Start" and "Finish" fields.
Finish Port	For TCP and UDP Services, enter the end of the range of port numbers used by the service. If the service uses a single port number, enter it in both the "Start" and "Finish" fields.
ICMP Type	For ICMP Services, enter the type number of the required service.
Buttons	
Delete	Delete the selected service from the list.
Save	Add a new entry to the Service list, using the data shown in the "Add

	New Service" area on screen.
Cancel	Clear the " Add New Service " area, ready for entering data for a new Service.

Access Control Log

To check the operation of the Access Control feature, an *Access Control Log* is provided. Click the *View Log* button on the *Access Control* screen to view this log.

This log shows attempted Internet accesses which have been **blocked** by the *Access Control* function.

Data shown in this log is as follows:

Date/Time	Date and Time of the attempted access.
Name	If known, the name of the PC whose access was blocked.
Source IP address	The IP Address of the PC or device whose access request was blocked
MAC address	The hardware or physical address of the PC or device whose access request was blocked
Destination	The destination URL or IP address

Dynamic DNS (Domain Name Server)

This free service is very useful when combined with the *Virtual Server* feature. It allows Internet users to connect to your Virtual Servers using a URL, rather than an IP Address.

This also solves the problem of having a dynamic IP address. With a dynamic IP address, your IP address may change whenever you connect, which makes it difficult to connect to you.

The Service works as follows:

1. You must register for the service at one of the listed DDNS Service Providers.
2. After registration, follow the service provider's procedure to request a Domain Name and have it allocated to you.
3. Enter your DDNS data on the WRT-413's DDNS screen.
4. The WRT-413 will then automatically ensure that your current IP Address is recorded at the DDNS server. If the DDNS Service provides software to perform this "IP address update"; you should disable the "Update" function, or not use the software at all.
5. From the Internet, users will be able to connect to your Virtual Servers (or DMZ PC) using your Domain Name.

Dynamic DNS Screen

Select *Advanced* on the main menu, then *Dynamic DNS*, you will see a screen as below:

DDNS (Dynamic DNS)

DDNS Service DDNS (Dynamic DNS) allows Internet users to connect to your Virtual Servers (or DMZ PC) using a domain name instead of an IP Address.

You must Register for the DDNS service at one of the listed Service suppliers.

DDNS Data

DDNS Service:

User Name:

Password/Key:

Domain Name: . .
Domain name allocated to you by the Service

DDNS Status: Username, password, and hostname must not be blank

Figure 35: DDNS Screen

Data - Dynamic DNS Screen

DDNS Service	
DDNS Service	<ul style="list-style-type: none">• Select the desired DDNS Service Provider from the list. You must register for the service at one of the listed Service Providers. You can reach the Service provider's Web Site by selecting them in the list and clicking the "Web Site" button.• Apply for a Domain Name, and ensure it is allocated to you.

	<ul style="list-style-type: none"> • Details of your DDNS account (Name, password, Domain name) must then be entered and saved on this screen. • This device will then automatically ensure that your current IP Address is recorded by the DDNS Service Provider. (You do NOT need to use the "Client" program provided by some DDNS Service providers.) • From the Internet, users will now be able to connect to your Virtual Servers (or DMZ PC) using your Domain name.
DDNS Data	
User Name	Enter your Username for the DDNS Service.
Password/Key	Enter your current password for the DDNS Service.
Domain Name	Enter the domain name allocated to you by the DDNS Service. If you have more than one name, enter the name you wish to use.
DDNS Status	<ul style="list-style-type: none"> • This message is returned by the DDNS Server • Normally, this message should be "Update successful" • If the message is "No host" or some other error message, you need to connect to the DDNS Service provider and correct the problem.

Advanced Internet Screen

This screen allows configuration of all advanced features relating to Internet access.

- Communication Applications
- Special Applications
- Multi-DMZ
- URL filter

An example screen is shown below.

Figure 36: Internet Screen

Communication Applications

Most applications are supported transparently by the WRT-413. But sometimes it is not clear which PC should receive an incoming connection. This problem could arise with the *Communication Applications* listed on this screen.

If this problem arises, you can use this screen to set which PC should receive an incoming connection, as described below.

Communication Applications	
Select an Application	This lists applications which may generate incoming connections, where the destination PC (on your local LAN) is unknown.

Send incoming calls to	<p>This lists the PCs on your LAN.</p> <ul style="list-style-type: none"> • If necessary, you can add PCs manually, using the "PC Database" option on the advanced menu. • For each application listed above, you can choose a destination PC. • There is no need to "Save" after each change; you can set the destination PC for each application, then click "Save".
-------------------------------	---

Special Applications

If you use Internet applications which use non-standard connections or port numbers, you may find that they do not function correctly because they are blocked by the WRT-413's firewall. In this case, you can define the application as a "Special Application".

Special Applications Screen

This screen can be reached by clicking the *Special Applications* button on the *Internet* screen.

You can then define your Special Applications. You will need detailed information about the application; this is normally available from the supplier of the application.

Also, note that the terms "Incoming" and "Outgoing" on this screen refer to traffic from the client (PC) viewpoint

Special Applications

Special Applications can only be used by 1 user at any time.

		Incoming Ports				Outgoing Ports			
Name		Type	Start	Finish	Type	Start	Finish		
1.	<input type="checkbox"/> <input style="width: 80px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>		
2.	<input type="checkbox"/> <input style="width: 80px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>		
3.	<input type="checkbox"/> <input style="width: 80px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>		
4.	<input type="checkbox"/> <input style="width: 80px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>		
5.	<input type="checkbox"/> <input style="width: 80px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>		
6.	<input type="checkbox"/> <input style="width: 80px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>	TCP ▾	<input style="width: 40px;" type="text"/>	<input style="width: 40px;" type="text"/>		

Figure 37: Special Applications Screen

Data - Special Applications Screen

Checkbox	Use this to Enable or Disable this Special Application as required.
Name	Enter a descriptive name to identify this Special Application.
Incoming Ports	<ul style="list-style-type: none">• Type - Select the protocol (TCP or UDP) used when you receive data from the special application or service. (Note: Some applications use different protocols for outgoing and incoming data).• Start - Enter the beginning of the range of port numbers used by the application server, for data you receive. If the application uses a single port number, enter it in both the "Start" and "Finish" fields.• Finish - Enter the end of the range of port numbers used by the application server, for data you receive.
Outgoing Ports	<ul style="list-style-type: none">• Type - Select the protocol (TCP or UDP) used when you send data to the remote system or service.• Start - Enter the beginning of the range of port numbers used by the application server, for data you send to it. If the application uses a single port number, enter it in both the "Start" and "Finish" fields.• Finish - Enter the end of the range of port numbers used by the application server, for data you send to it. If the application uses a single port number, enter it in both the "Start" and "Finish" fields.

Using a Special Application

- Configure the *Special Applications* screen as required.
- On your PC, use the application normally. Remember that only one (1) PC can use each Special application at any time. Also, when 1 PC is finished using a particular Special Application, there may need to be a "Time-out" before another PC can use the same Special Application. The "Time-out" period may be up to 3 minutes.



Note!

If an application still cannot function correctly, try using the "DMZ" feature.

Multi-DMZ

This feature, if enabled, allows the DMZ computer or computers on your LAN to be exposed to all users on the Internet.

- This allows almost any application to be used on the "DMZ PC".
- The "DMZ PC" will receive all "Unknown" connections and data.
- If the DMZ feature is enabled, you must select the PC to be used as the "DMZ PC".

If you have multiple Internet IP addresses, you can assign one DMZ PC for each Internet IP address.

If you only have 1 WAN IP address, only "DMZ 1" can be used, and only one (1) PC can be the DMZ PC. The current WAN IP address is displayed. If this address is assigned upon connection, and no connection currently exists, then this address will be blank or 0.0.0.0.



The "DMZ PC" is effectively outside the Firewall, making it more vulnerable to attacks. For this reason, you should only enable the DMZ feature when required.

URL Filter

The URL Filter allows you to block access to undesirable Web site

- To use this feature, you must define "filter strings". If the "filter string" appears in a requested URL, the request is blocked.
- Enabling the **URL Filter** also affects the Internet **Access Log**. If Enabled, the "Destination" field in the log will display the URL. Otherwise, it will display the IP Address.

URL Filter Screen

Click the "Configure URL Filter" button on the **Internet** screen to access the **URL Filter** screen. The screen is shown below.

Figure 38: URL Filter Screen

Data - URL Filter Screen

Filter Strings	
Current Entries	This lists any existing entries. If you have not entered any values, this list will be empty.
Add Filter String	To add an entry to the list, enter it here, and click the "Add" button. An entry may be a Domain name (e.g. www.trash.com) or simply a string. (e.g. ads/) Any URL which contains ANY entry ANYWHERE in the URL will be blocked.

Buttons	
Delete/Delete All	Use these buttons to delete the selected entry or all entries, as required. Multiple entries can be selected by holding down the CTRL key while selecting.(On the Macintosh, hold the SHIFT key while selecting.)
Add	Use this to add the current Filter String to the site list.

Virtual Servers

This feature, sometimes called **Port Forwarding**, allows you to make Servers on your LAN accessible to Internet users. Normally, Internet users would not be able to access a server on your LAN because:

- Your Server does not have a valid external IP Address.
- Attempts to connect to devices on your LAN are blocked by the firewall in this device.

The "Virtual Server" feature solves these problems and allows Internet users to connect to your servers, as illustrated below.




Figure 39: Virtual Servers

IP Address seen by Internet Users

Note that, in this illustration, both Internet users are connecting to the same IP Address, but using different protocols.

To Internet users, all virtual Servers on your LAN have the same IP Address. This IP Address is allocated by your ISP.

This address should be static, rather than dynamic, to make it easier for Internet users to connect to your Servers. However, you can use the **DDNS** (*Dynamic DNS*) feature to allow users to connect to your Virtual Servers using a URL, instead of an IP Address.

Virtual Servers Screen

This screen lists a number of pre-defined Servers, and allows you to define your own Servers. Details of the selected Server are shown in the "Properties" area.

Figure 40: Virtual Servers Screen

Data - Virtual Servers Screen

Servers	
Servers	This lists a number of pre-defined Servers, plus any Servers you have defined. Details of the selected Server are shown in the "Properties" area.
Properties	
Enable	Use this to Enable or Disable support for this Server, as required. <ul style="list-style-type: none"> • If Enabled, any incoming connections will be forwarded to the selected PC. • If Disabled, any incoming connection attempts will be blocked.
PC (Server)	Select the PC for this Server. The PC must be running the appropriate Server software.
Protocol	Select the protocol (TCP or UDP) used by the Server.
Internal Port No.	Enter the port number which the Server software is configured to use.
External Port No.	The port number used by Internet users when connecting to the Server. This is normally the same as the Internal Port Number. If it is different, this device will perform a "mapping" or "translation" function, allowing the server to use one port address, while clients use a different port address.

Buttons	
Defaults	This will delete any Servers you have defined, and set the pre-defined Servers to use their default port numbers.
Disable All	This will cause the "Enable" setting of all Virtual Servers to be set OFF.
Update Selected Server	Update the current Virtual Server entry, using the data shown in the "Properties" area on screen.
Add as new Server	Add a new entry to the Virtual Server list, using the data shown in the "Properties" area on screen. The entry selected in the list is ignored, and has no effect.
Delete	Delete the current Virtual Server entry. Note that the pre-defined Servers can not be deleted. Only Servers you have defined yourself can be deleted.
Clear Form	Clear all data from the "Properties" area, ready for input of a new Virtual Server entry.



For each entry, the PC must be running the appropriate Server software.

Defining your own Virtual Servers

If the type of Server you wish to use is not listed on the *Virtual Servers* screen, you can define and manage your own Servers:

- Create a new Server:**
1. Click "Clear Form"
 2. Enter the required data, as described above.
 3. Click "Add".
 4. The new Server will now appear in the list.
- Modify (Edit) a Server:**
1. Select the desired Server from the list
 2. Make any desired changes (for example, change the Enable/Disable setting).
 3. Click "Update" to save changes to the selected Server.
- Delete a Server:**
1. Select the entry from the list.
 2. Click "Delete".

Note: You can only delete Servers you have defined. Pre-defined Server cannot be deleted.



From the Internet, ALL Virtual Servers have the IP Address allocated by your ISP.

Connecting to the Virtual Servers

Once configured, anyone on the Internet can connect to your Virtual Servers. They must use the Internet IP Address (the IP Address allocated to you by your ISP).

e.g.

`http://203.70.212.52`

`ftp://203.70.212.52`

It is more convenient if you are using a Fixed IP Address from your ISP, rather than Dynamic. However, you can use the ***Dynamic DNS*** feature, described in the following section, to allow users to connect to your Virtual Servers using a URL, rather than an IP Address.

WAN Port Configuration

In this screen, you can configure the WAN port settings.

Figure 41: WAN Port Screen

Data – WAN Port Screen

Identification	
Hostname	Normally, there is no need to change the default name, but if your ISP requests that you use a particular Hostname, enter it here.
Domain Name	If your ISP provided a domain name, enter it here. Otherwise, this may be left blank.
WAN Port MAC Address	<p>Also called <i>Network Adapter Address</i> or <i>Physical Address</i>. This is a low-level identifier, as seen from the WAN port.</p> <p>Normally there is no need to change this, but some ISPs require a particular value, often that of the PC initially used for Internet access.</p> <p>You can use the Copy from PC button to copy your PC's address into this field, the Default button to insert the default value, or enter a value directly.</p>
IP Address	
Automatic	<p>Also called Dynamic IP Address. This is the default, and the most common.</p> <p>Leave this selected if your ISP allocates an IP Address to the WRT-413 upon connection.</p>

Specified IP Address	<p>Also called Static IP Address. Select this if your ISP has allocated you a fixed IP Address. If this option is selected, the following data must be entered.</p> <ul style="list-style-type: none"> • IP Address The IP Address allocated by the ISP. • Network Mask (Not required for PPPoE) This is also supplied by your ISP. It must be compatible with the IP Address above. • Gateway IP Address (Not required for PPPoE) The address of the router or gateway, as supplied by your ISP.
DNS	
Automatically obtain from Server	<p>The DNS (Domain Name Server) address will be obtained automatically from your ISP's server.</p> <p>Note that if using a fixed IP address, with no login (login is set to "None"), then no Server is used, so this option cannot be used.</p>
Use this DNS	<p>If this option is selected, you must enter the IP address of the DNS (Domain Name Server) you wish to use.</p> <p>Note: If the DNS is unavailable, the "Backup DNS", entered on the "Options" screen, will be used</p>
Login	
Login Method	<p>If your ISP does not use a login method (username, password) for Internet access, leave this at the default value None (Direct connection). Otherwise, check the documentation from your ISP, select the login method used, and enter the required data.</p> <ul style="list-style-type: none"> • PPPoE - this is the most common login method, widely used with xDSL modems. Normally, your ISP will have provided some software to connect and login. This software is no longer required, and should not be used. • PPPoE (Unnumbered IP) - this can only be used if your ISP supports this system, and has allocated you multiple IP addresses. If selected, you must also select "Specified IP Address" above and enter one of the IP addresses allocated to you by your ISP. • PPTP - this is mainly used in Europe. You need to know the PPTP Server address as well as your name and password. • L2TP - this is not widely used. You need to know the PPTP Server address as well as your name and password. • Big Pond Cable - for Australia only. • SingTel RAS - for Singapore only.
Login User Name	The User Name (or account name) provided by your ISP.
Login Password	Enter the password for the login name above.
RAS Plan	For SingTel customers only, select the RAS plan you are on.
Server Address	<p>This is not required for PPPoE or SingTel RAS.</p> <p>For PPTP, L2TP and BPA, enter the Server address as provided by your ISP.</p>

Connection Behavior	<p>Select the desired option:</p> <ul style="list-style-type: none"> • Automatic Connect/Disconnect An Internet connection is automatically made when required, and disconnected when idle for the time period specified by the "Auto-disconnect Idle Time-out". • Manual Connect/Disconnect You must manually establish and terminate the connection. • Keep alive (maintain connection) The connection will never be disconnected by this device. If disconnected by your ISP, the connection will be re-established immediately. (However, this does not ensure that your Internet IP address will remain unchanged.)
Auto-disconnect Idle Time-out	<p>This field has no effect unless using the Automatic Connect/Disconnect setting.</p> <p>If using this setting, enter the desired idle time-out period (in minutes). After the connection to your ISP has been idle for this time period, the connection will be terminated.</p>
Buttons	
Default	Inserts the default MAC address into the MAC address field. You must click "Save" to actually change the address used.
Copy from PC	Inserts the MAC address from your PC into the MAC address field. You must click "Save" to actually change the address used.
Save	Save your changes to the WRT-413.
Cancel	Reverse any changes made since the last "Save".

Chapter 7

Advanced Administration



This Chapter explains the settings available via the "Administration" section of the menu.

Overview

Normally, it is not necessary to use these screens, or change any settings. These screens and settings are provided to deal with non-standard situations, or to provide additional options for advanced users.

The available settings and features are:

Config File	Backup or restore the configuration file for the WRT-413. This file contains all the configuration data.
Logs	View or clear all logs, set E-Mailing of log files.
Network Diagnostics	Ping, DNS Lookup.
Options	Various options, such as backup DNS, UPnP, and enable TFTP firmware upgrade option.
PC Database	This is the list of PCs shown when you select the "DMZ PC" or a "Virtual Server". This database is maintained automatically, but you can add and delete entries for PCs which use a Fixed (Static) IP Address.
Remote Administration	Allow settings to be changed from the Internet..
Routing	Only required if your LAN has other Routers or Gateways.
Security	Firewall and other security-related settings. Normally, the default settings do not need to be changed.
Firmware Upgrade	Upgrade the Firmware (software) installed in your WRT-413.

Config File

This feature allows you to download the current settings from the WRT-413, and save them to a file on your PC.

You can restore a previously-downloaded configuration file to the WRT-413, by uploading it to the WRT-413.

This screen also allows you to set the WRT-413 back to its factory default configuration. Any existing settings will be deleted.

An example *Config File* screen is shown below.

The screenshot shows a web interface titled "Config File" in a dark blue header. On the left is a vertical blue sidebar with three white text labels: "Backup Config", "Restore Config", and "Default Config". The main area has a white background. Under "Backup Config", it says "Download a copy of the current settings." with a "Download" button. Under "Restore Config", it says "Restore previously saved settings from a file." followed by a text input field, a "Browse..." button, and a "Restore" button. Under "Default Config", it says "Restore factory default settings." with a "Restore Defaults" button. At the bottom right are "Cancel" and "Help" buttons.

Figure 42: Config Screen

Data - Config File Screen

Backup Config	Use this to download a copy of the current configuration, and store the file on your PC. Click Download to start the download.
Restore Config	<p>This allows you to restore a previously-saved configuration file back to the WRT-413.</p> <p>Click Browse to select the configuration file, then click Restore to upload the configuration file.</p> <p>WARNING !</p> <p>Uploading a configuration file will destroy (overwrite) ALL of the existing settings.</p>
Default Config	<p>Clicking the Restore Defaults button will reset the WRT-413 to its factory default settings.</p> <p>WARNING !</p> <p>This will delete ALL of the existing settings.</p>

Logs

The Logs record various types of activity on the WRT-413. This data is useful for troubleshooting, but enabling all logs will generate a large amount of data and adversely affect performance.

Since only a limited amount of log data can be stored in the WRT-413, log data can also be E-mailed to your PC.

Figure 43: Logs Screen

Data - Logs Screen

Enable Logs	
Outgoing Connections	If selected, Outgoing Internet connections are logged. Normally, the (Internet) "Destination" will be shown as an IP address. But if the "URL Filter" is enabled, the "Destination" will be shown as a URL.
Access Control	If enabled, the log will include attempted outgoing connections which have been blocked by the "Access Control" feature.
DoS Attacks	If enabled, this log will show details of DoS (Denial of Service) attacks which have been blocked by the built-in Firewall.
Timezone	Select the correct Timezone for your location. This is required for the date/time shown on the logs to be correct.
E-Mail Reports	
Send E-mail alert	If enabled, an E-mail will be sent immediately if a DoS (Denial of Service) attack is detected. If enabled, the E-mail address information must be provided.

E-mail Logs	You can choose to have the logs E-mailed to you, by enabling either or both checkboxes. If enabled, the Log will be sent to the specified E-mail address. The interval between E-mails is determined by the "Send" setting.
Send	<p>Select the desired option for sending the log by E-mail.</p> <ul style="list-style-type: none"> • When log is full - The time is not fixed. The log will be sent when the log is full, which will depend on the volume of traffic. • Every day, Every Monday ... - The log is sent on the interval specified. <ul style="list-style-type: none"> • If "Every day" is selected, the log is sent at the time specified. • If the day is specified, the log is sent once per week, on the specified day. • Select the time of day you wish the E-mail to be sent. • If the log is full before the time specified to send it, it will be sent regardless.
E-Mail Address	
E-mail Address	Enter the E-mail address the Log is to be sent to. The E-mail will also show this address as the Sender's address.
Subject	Enter the text string to be shown in the "Subject" field for the E-mail.
SMTP Server	Enter the address or IP address of the SMTP (Simple Mail Transport Protocol) Server you use for outgoing E-mail.
Port No.	Enter the port number used to connect to the SMTP Server. The default value is 25.

Network Diagnostics

This screen allows you to perform a "Ping" or a "DNS lookup". These activities can be useful in solving network problems.

An example *Network Diagnostics* screen is shown below.

Figure 44: Network Diagnostics Screen

Data - Network Diagnostics Screen

Ping	
Ping this IP Address	Enter the IP address you wish to ping. The IP address can be on your LAN, or on the Internet. Note that if the address is on the Internet, and no connection currently exists, you could get a "Timeout" error. In that case, wait a few seconds and try again.
Ping Button	After entering the IP address, click this button to start the "Ping" procedure. The results will be displayed in the <i>Ping Results</i> pane.
DNS Lookup	
Domain name/URL	Enter the Domain name or URL for which you want a DNS (Domain Name Server) lookup. Note that if the address is on the Internet, and no connection currently exists, you could get a "Timeout" error. In that case, wait a few seconds and try again.
Lookup Button	After entering the Domain name/URL, click this button to start the "DNS Lookup" procedure. The results will be displayed in the <i>DNS Lookup Results</i> pane.

Options

This screen allows advanced users to enter or change a number of settings. For normal operation, there is no need to use this screen or change any settings.

An example *Options* screen is shown below.

The screenshot shows a web-based configuration interface titled "Options". On the left is a blue sidebar with menu items: "Backup DNS", "TFTP", "UPnP", and "MTU". The main content area is white and displays the following settings:

- Backup DNS:** Two input fields for "Backup DNS (1) IP Address:" and "Backup DNS (2) IP Address:". Below them is a note: "These DNS (Domain Name Servers) are used only if the primary DNS is unavailable."
- TFTP:** A checkbox labeled "Enable Firmware Upgrade using TFTP" which is currently unchecked.
- UPnP:** A checked checkbox labeled "Enable UPnP Services". Below it are two more checkboxes: "Allow configuration changes through UPnP" (checked) and "Allow Internet access to be disabled" (unchecked).
- MTU:** A text input field for "MTU (Maximum Transmission Unit):" with the value "1500" and a range "(1..1500) bytes". Below it is a note: "This setting only affects PPPoE, L2TP and PPTP connections."

At the bottom right of the main area are three buttons: "Save", "Cancel", and "Help".

Figure 45: Options Screen

Data - Options Screen

Backup DNS	
IP Address	Enter the IP Address of the DNS (Domain Name Servers) here. These DNS will be used only if the primary DNS is unavailable.
TFTP	
Enable Firm-ware Upgrade using TFTP	<ul style="list-style-type: none"> If enabled, TFTP (Trivial FTP) can be used to upgrade the firm-ware in this device. This is normally not required; a Windows utility is available for this purpose. You must obtain the firmware upgrade file first; instructions for using TFTP will be available with the upgrade.
UPnP	
Enable UPnP Services	<ul style="list-style-type: none"> UPnP (Universal Plug and Play) allows automatic discovery and configuration of equipment attached to your LAN. UPnP is by supported by Windows ME, XP, or later. If Enabled, this device will be visible via UPnP. If Disabled, this device will not be visible via UPnP.
Allow Configu-ration...	<ul style="list-style-type: none"> If checked, then UPnP users can change the configuration. If Disabled, UPnP users can only view the configuration. But currently, this restriction only applies to users running Windows XP, who access the <i>Properties</i> via UPnP. (e.g. Right - click the WRT-413 in <i>My Network Places</i>, and select <i>Properties</i>)

Allow Internet access to be disabled	<ul style="list-style-type: none"> • If checked, then UPnP users can disable Internet access via this device. • If Disabled, UPnP users can NOT disable Internet access via this device. But currently, this restriction only applies to users running Windows XP, who access the <i>Properties</i> via UPnP. (e.g. Right - click the WRT-413 in <i>My Network Places</i>, and select <i>Properties</i>)
MTU	
MTU size	<p>MTU (Maximum Transmission Unit) value should only be changed if advised to do so by Technical Support.</p> <ul style="list-style-type: none"> • Enter a value between 1 and 1500. • This device will still auto-negotiate with the remote server, to set the MTU size. The smaller of the 2 values (auto-negotiated, or entered here) will be used. • For direct connections (not PPPoE or PPTP), the MTU used is always 1500.

PC Database

The PC Database is used whenever you need to select a PC (e.g. for the "DMZ" PC). It eliminates the need to enter IP addresses. Also, you do not need to use fixed IP addresses on your LAN.

PC Database Screen

An example *PC Database* screen is shown below.

PC Database

DHCP Clients are automatically added and updated.
If not listed, try restarting the PC.
PCs using a Fixed IP address can be added and deleted below.

Known PCs

unknown 192.168.0.12 (LAN) (DHCP)

< Add

Delete

Refresh Generate Report

Advanced Administration Help

Figure 46: PC Database

- PCs which are "DHCP Clients" are automatically added to the database, and updated as required.
- By default, non-Server versions of Windows act as "DHCP Clients"; this setting is called "Obtain an IP Address automatically".
- The WRT-413 uses the "Hardware Address" to identify each PC, not the name or IP address. The "Hardware Address" can only change if you change the PC's network card or adapter.
- This system means you do NOT need to use Fixed (static) IP addresses on your LAN. However, you can add PCs using Fixed (static) IP Addresses to the PC database if required.

Data - PC Database Screen

Known PCs	This lists all current entries. Data displayed is <i>name (IP Address) type</i> . The "type" indicates whether the PC is connected to the LAN.
Name	If adding a new PC to the list, enter its name here. It is best if this matches the PC's "hostname".
IP Address	Enter the IP Address of the PC. The PC will be sent a "ping" to determine its hardware address. If the PC is not available (not connected, or not powered On) you will not be able to add it.
Buttons	
Add	This will add the new PC to the list. The PC will be sent a "ping" to determine its hardware address. If the PC is not available (not connected, or not powered On) you will not be able to add it.
Delete	Delete the selected PC from the list. This should be done in 2 situations: <ul style="list-style-type: none">• The PC has been removed from your LAN.• The entry is incorrect.
Refresh	Update the data on screen.
Generate Report	Display a read-only list showing full details of all entries in the PC database.
Advanced Administration	View the Advanced version of the PC database screen - <i>PC Database (Admin)</i> . See below for details.

PC Database (Admin)

This screen is displayed if the "Advanced Administration" button on the *PC Database* is clicked. It provides more control than the standard *PC Database* screen.

Any PC may be added, edited or deleted. If adding a PC which is not connected and On, you must provide the MAC (hardware) address

Known PCs
unknown 192.168.0.12 (LAN) 00e018884b53(DHCP)

Edit Delete

PC Properties

Name:

IP Address: ☒ Automatic (DHCP Client)
☐ DHCP Client - reserved IP address:
☐ Fixed IP address (set on PC):

MAC Address: ☒ Automatic discovery (PC must be available on LAN)
☐ MAC address is

Add as New Entry Update Selected PC Clear Form

Refresh Generate Report Standard Screen Help

Figure 47: PC Database (Admin)

Data - PC Database (Admin) Screen

Known PCs	This lists all current entries. Data displayed is <i>name (IP Address) type</i> . The "type" indicates whether the PC is connected to the LAN.
PC Properties	
Name	If adding a new PC to the list, enter its name here. It is best if this matches the PC's "hostname".
IP Address	<p>Select the appropriate option:</p> <ul style="list-style-type: none"> Automatic - The PC is set to be a DHCP client (Windows: "Obtain an IP address automatically"). The WRT-413 will allocate an IP address to this PC when requested to do so. The IP address could change, but normally won't. DCHP Client - Reserved IP Address - Select this if the PC is set to be a DCHP client, and you wish to guarantee that the WRT-413 will always allocate the same IP Address to this PC. Enter the required IP address. Only the last field is required; the other fields must match the WRT-413's IP address. Fixed IP Address - Select this if the PC is using a Fixed (Static) IP address. Enter the IP address allocated to the PC. (The PC must be configured to use this IP address.)

MAC Address	<p>Select the appropriate option</p> <ul style="list-style-type: none"> • Automatic discovery - Select this to have the WRT-413 contact the PC and find its MAC address. This is only possible if the PC is connected to the LAN and powered On. • MAC is - Enter the MAC address on the PC. The MAC address is also called the "Hardware Address", "Physical Address", or "Network Adapter Address". The WRT-413 uses this to provide a unique identifier for each PC. Because of this, the MAC address can NOT be left blank.
Buttons	
Add as New Entry	<p>Add a new PC to the list, using the data in the "Properties" box. If "Automatic discovery" (for MAC address) is selected, the PC will be sent a "ping" to determine its hardware address. This will fail unless the PC is connected to the LAN, and powered on.</p>
Update Selected PC	<p>Update (modify) the selected PC, using the data in the "Properties" box.</p>
Clear Form	<p>Clear the "Properties" box, ready for entering data for a new PC.</p>
Refresh	<p>Update the data on screen.</p>
Generate Report	<p>Display a read-only list showing full details of all entries in the PC database.</p>
Standard Screen	<p>Click this to view the standard <i>PC Database</i> screen.</p>

Remote Admin

If enabled, this feature allows you to manage the WRT-413 via the Internet.




Figure 48: Remote Administration Screen

Data - Remote Administration Screen

Remote Administration	
Enable Remote Management	Enable to allow management via the Internet. If Disabled, this device will ignore management connection attempts from the Internet.
Port Number	<p>Enter a port number between 1024 and 65535 (8080 is recommended). This port number must be specified when you connect (see below).</p> <p>Note: The default port number for HTTP (Web) connections is port 80, but using port 80 here will prevent the use of a Web "Virtual Server" on your LAN. (See <i>Advanced Internet - Virtual Servers</i>)</p>
Current IP Address	<p>You must use this IP Address to connect (see below).</p> <p>This IP Address is allocated by your ISP. But if using a Dynamic IP Address, this value can change each time you connect to your ISP. So it is better if your ISP allocates you a Fixed IP Address.</p>

To connect from a remote PC via the Internet

1. Ensure your Internet connection is established, and start your Web Browser.
2. In the "Address" bar, enter "HTTP://" followed by the Internet IP Address of the WRT-413. If the port number is not 80, the port number is also required. (After the IP Address, enter ":" followed by the port number.)
e.g.

HTTP://123.123.123.123:8080

This example assumes the WAN IP Address is 123.123.123.123, and the port number is 8080.

Routing

Overview

- If you don't have other Routers or Gateways on your LAN, you can ignore the "Routing" page completely.
- If the WRT-413 is only acting as a Gateway for the local LAN segment, ignore the "Routing" page even if your LAN has other Routers.
- If your LAN has a standard Router (e.g. Cisco) on your LAN, and the WRT-413 is to act as a Gateway for all LAN segments, enable RIP (Routing Information Protocol) and ignore the Static Routing table.
- If your LAN has other Gateways and Routers, and you wish to control which LAN segments use each Gateway, do NOT enable RIP (Routing Information Protocol). Configure the Static Routing table instead. (You also need to configure the other Routers.)
- If using Windows 2000 Data center Server as a software Router, enable RIP on the WRT-413, and ensure the following Windows 2000 settings are correct:
 - Open **Routing and Remote Access**
 - In the console tree, select **Routing and Remote Access** , [**server name**], **IP Routing**, **RIP**
 - In the "Details" pane, right-click the interface you want to configure for RIP version 2, and then click "Properties".
 - On the "General" tab, set **Outgoing packet protocol** to "RIP version 2 broadcast", and **Incoming packet protocol** to "RIP version 1 and 2".

Routing Screen

The routing table is accessed by the **Routing** link on the **Administration** menu.

Using this Screen

Generally, you will use either RIP (Routing Information Protocol) OR the Static Routing Table, as explained above, although it is possible to use both methods simultaneously.

Static Routing Table

- If RIP is not used, an entry in the routing table is required for each LAN segment on your Network, other than the segment to which this device is attached.
- The other Routers must also be configured. See **Configuring Other Routers on your LAN** later in this chapter for further details and an example.

Figure 49: Routing Screen

Data - Routing Screen

RIP	
Enable RIP	<p>Check this to enable the RIP (Routing Information Protocol) feature of the WRT-413.</p> <p>The WRT-413 supports RIP 1 only.</p>
Static Routing	
Static Routing Table Entries	<p>This list shows all entries in the Routing Table.</p> <ul style="list-style-type: none"> The "Properties" area shows details of the selected item in the list. Change any the properties as required, then click the "Update" button to save the changes to the selected entry.
Properties	<ul style="list-style-type: none"> Destination Network - The network address of the remote LAN segment. For standard class "C" LANs, the network address is the first 3 fields of the Destination IP Address. The 4th (last) field can be left at 0. Network Mask - The Network Mask for the remote LAN segment. For class "C" networks, the default mask is 255.255.255.0 Gateway IP Address - The IP Address of the Gateway or Router which the WRT-413 must use to communicate with the destination above. (NOT the router attached to the remote segment.) Metric - The number of "hops" (routers) to pass through to reach the remote LAN segment. The shortest path will be used. The default value is 1.
Buttons	
Save	Save the RIP setting. This has no effect on the Static Routing Table.

Add	Add a new entry to the Static Routing table, using the data shown in the "Properties" area on screen. The entry selected in the list is ignored, and has no effect.
Update	Update the current Static Routing Table entry, using the data shown in the "Properties" area on screen.
Delete	Delete the current Static Routing Table entry.
Clear Form	Clear all data from the "Properties" area, ready for input of a new entry for the Static Routing table.
Generate Report	Generate a read-only list of all entries in the Static Routing table.

Configuring Other Routers on your LAN

It is essential that all IP packets for devices not on the local LAN be passed to the WRT-413, so that they can be forwarded to the external LAN, WAN, or Internet. To achieve this, the local LAN must be configured to use the WRT-413 as the *Default Route* or *Default Gateway*.

Local Router

The local router is the Router installed on the same LAN segment as the WRT-413. This router requires that the *Default Route* is the WRT-413 itself. Typically, routers have a special entry for the *Default Route*. It should be configured as follows.

Destination IP Address	Normally 0.0.0.0, but check your router documentation.
Network Mask	Normally 0.0.0.0, but check your router documentation.
Gateway IP Address	The IP Address of the WRT-413.
Metric	1

Other Routers on the Local LAN

Other routers on the local LAN must use the WRT-413's *Local Router* as the *Default Route*. The entries will be the same as the WRT-413's local router, with the exception of the *Gateway IP Address*.

- For a router with a direct connection to the WRT-413's local Router, the *Gateway IP Address* is the address of the WRT-413's local router.
- For routers which must forward packets to another router before reaching the WRT-413's local router, the *Gateway IP Address* is the address of the intermediate router.

Static Routing - Example




Figure 50: Routing Example

For the WRT-413's Routing Table

For the LAN shown above, with 2 routers and 3 LAN segments, the WRT-413 requires 2 entries as follows.

Entry 1 (Segment 1)	
Destination IP Address	192.168.1.0
Network Mask	255.255.255.0 (Standard Class C)
Gateway IP Address	192.168.0.100 (WRT-413's local Router)
Metric	2
Entry 2 (Segment 2)	
Destination IP Address	192.168.2.0
Network Mask	255.255.255.0 (Standard Class C)
Gateway IP Address	192.168.0.100
Metric	3

For Router A's Default Route

Destination IP Address	0.0.0.0
Network Mask	0.0.0.0
Gateway IP Address	192.168.0.1 (WRT-413's IP Address)

For Router B's Default Route

Destination IP Address	0.0.0.0
Network Mask	0.0.0.0
Gateway IP Address	192.168.1.80 (WRT-413's local router)

Security

This screen allows you to set Firewall and other security-related options.

Figure 51: Security Screen

Data - Security Screen


Firewall	
Enable DoS Firewall	<p>If enabled, DoS (Denial of Service) attacks will be detected and blocked. The default is enabled. It is strongly recommended that this setting be left enabled.</p> <p>Note:</p> <ul style="list-style-type: none"> A DoS attack does not attempt to steal data or damage your PCs, but overloads your Internet connection so you can not use it - the service is unavailable. This device uses "Stateful Inspection" technology. This system can detect situations where individual TCP/IP packets are valid, but collectively they become a DoS attack.
Threshold	<p>This setting affects the number of "half-open" connections allowed.</p> <ul style="list-style-type: none"> A "half-open" connection arises when a remote client contacts the Server with a connection request, but then does not reply to the Server's response. While the optimum number of "half-open" connections allowed (the "Threshold") depends on many factors, the most important factor is the available bandwidth of your Internet connection. Select the setting to match the bandwidth of your Internet connection.

Options	
Respond to ICMP	<p>The ICMP protocol is used by the "ping" and "traceroute" programs, and by network monitoring and diagnostic programs.</p> <ul style="list-style-type: none"> • If checked, the WRT-413 will respond to ICMP packets received from the Internet. • If not checked, ICMP packets from the Internet will be ignored. Disabling this option provides a slight increase in security.
Allow IPsec	<p>The IPsec protocol is used to establish a secure connection, and is widely used by VPN (Virtual Private Networking) programs.</p> <ul style="list-style-type: none"> • If checked, IPsec connections are allowed. • If not checked, IPsec connections are blocked.
Allow PPTP	<p>PPTP (Point to Point Tunneling Protocol) is widely used by VPN (Virtual Private Networking) programs.</p> <ul style="list-style-type: none"> • If checked, PPTP connections are allowed. • If not checked, PPTP connections are blocked.
Allow L2TP	<p>L2TP is a protocol developed by Cisco for VPNs (Virtual Private Networks).</p> <ul style="list-style-type: none"> • If checked, L2TP connections are allowed. • If not checked, L2TP connections are blocked.

Upgrade Firmware

The firmware (software) in the WRT-413 can be upgraded using your Web Browser.

You must first download the upgrade file, then select *Upgrade* on the *Administration* menu. You will see a screen as below.



Upgrade Firmware

The upgrade firmware file needs to be downloaded and stored on your PC.

Wireless Router Password:

Upgrade File:

Figure 52: Upgrade Firmware Screen

To perform the Firmware Upgrade:

3. Click the "Browse" button and navigate to the location of the upgrade file.
4. Select the upgrade file. Its name will appear in the *Upgrade File* field.
5. Click the "Start Upgrade" button to commence the firmware upgrade.



The WRT-413 is unavailable during the upgrade process, and must restart when the upgrade is completed. Any connections to or through the WRT-413 will be lost.

Appendix A

Troubleshooting



This Appendix covers the most likely problems and their solutions.

Overview

This chapter covers some common problems that may be encountered while using the WRT-413 and some possible solutions to them. If you follow the suggested steps and the WRT-413 still does not function properly, contact your dealer for further advice.

General Problems

Problem 1: Can't connect to the WRT-413 to configure it.

Solution 1: Check the following:

- The WRT-413 is properly installed, LAN connections are OK, and it is powered ON.
- Ensure that your PC and the WRT-413 are on the same network segment. (If you don't have a router, this must be the case.)
- If your PC is set to "Obtain an IP Address automatically" (DHCP client), restart it.
- If your PC uses a Fixed (Static) IP address, ensure that it is using an IP Address within the range 192.168.0.2 to 192.168.0.254 and thus compatible with the WRT-413's default IP Address of 192.168.0.1. Also, the Network Mask should be set to 255.255.255.0 to match the WRT-413.
In Windows, you can check these settings by using *Control Panel-Network* to check the *Properties* for the TCP/IP protocol.

Internet Access

Problem 1: When I enter a URL or IP address I get a time out error.

Solution 1: A number of things could be causing this. Try the following troubleshooting steps.

- Check if other PCs work. If they do, ensure that your PCs IP settings are correct. If using a Fixed (Static) IP Address, check the Network Mask, Default gateway and DNS as well as the IP Address.
- If the PCs are configured correctly, but still not working, check the WRT-413. Ensure that it is connected and ON. Connect to it and check its settings. (If you can't connect to it, check the LAN and power connections.)
- If the WRT-413 is configured correctly, check your Internet connection (xDSL/Cable modem etc) to see that it is working correctly.

Problem 2: Some applications do not run properly when using the WRT-413.

- Solution 2:** The WRT-413 processes the data passing through it, so it is not transparent. Use the *Special Applications* feature to allow the use of Internet applications which do not function correctly.
- If this does solve the problem you can use the *DMZ* function. This should work with almost every application, but:
- It is a security risk, since the firewall is disabled.
 - Only one (1) PC can use this feature.

Wireless Access

Problem 1: My PC can't locate the Wireless Access Point.

Solution 1: Check the following.

- Your PC is set to *Infrastructure Mode*. (Access Points are always in *Infrastructure Mode*)
- The SSID on your PC and the Wireless Access Point are the same. Remember that the SSID is case-sensitive. So, for example "Workgroup" does NOT match "workgroup".
- Both your PC and the WRT-413 must have the same setting for WEP. The default setting for the WRT-413 is disabled, so your wireless client should also have WEP disabled.
- If WEP is enabled on the WRT-413, your PC must have WEP enabled, and the key must match.
- If the WRT-413's *Wireless* screen is set to *Allow LAN access to selected Wireless Clients only*, then each of your Wireless clients must have been selected, or access will be blocked.
- To see if radio interference is causing a problem, see if connection is possible when close to the WRT-413. Remember that the connection range can be as little as 100 feet in poor environments.

Problem 2: Wireless connection speed is very slow.

Solution 2: The wireless system will connect at the highest possible speed, depending on the distance and the environment. To obtain the highest possible connection speed, you can experiment with the following:

- WRT-413 location.
Try adjusting the location and orientation of the WRT-413.
- Wireless Channel
If interference is the problem, changing to another channel may show a marked improvement.
- Radio Interference
Other devices may be causing interference. You can experiment by switching other devices Off, and see if this helps. Any "noisy" devices should be shielded or relocated.
- RF Shielding
Your environment may tend to block transmission between the wireless clients. This will mean high access speed is only possible when close to the WRT-413.

Appendix B

About Wireless LANs



This Appendix provides some background information about using Wireless LANs (WLANs).

Modes

Wireless LANs can work in either of two (2) modes:

- Ad-hoc
- Infrastructure

Ad-hoc Mode

Ad-hoc mode does not require an Access Point or a wired (Ethernet) LAN. Wireless Clients (e.g. notebook PCs with wireless cards) communicate directly with each other.

Infrastructure Mode

In Infrastructure Mode, one or more Access Points are used to connect Wireless Clients (e.g. Notebook PCs with wireless cards) to a wired (Ethernet) LAN. The Wireless Clients can then access all LAN resources.



Access Points can only function in "Infrastructure" mode, and can communicate only with Wireless Clients which are set to "Infrastructure" mode.

BSS/ESS

BSS

A group of Wireless Clients and a single Access Point, all using the same ID (SSID), form a Basic Service Set (BSS).

Using the same SSID is essential. Devices with different SSIDs are unable to communicate with each other.

ESS

A group of Wireless Clients, and multiple Access Points, all using the same ID (ESSID), form an Extended Service Set (ESS).

Different Access Points within an ESS can use different Channels. In fact, to reduce interference, it is recommended that adjacent Access Points **SHOULD** use different channels.

As Wireless Clients are physically moved through the area covered by an ESS, they will automatically change to the Access Point which has the least interference or best performance. This capability is called **Roaming**. (Access Points do not have or require Roaming capabilities.)

Channels

The Wireless Channel sets the radio frequency used for communication.

- Access Points use a fixed Channel. You can select the Channel used. This allows you to choose a Channel which provides the least interference and best performance. In the USA and Canada, 11 channels are available. If using multiple Access Points, it is better if adjacent Access Points use different Channels to reduce interference.
- In "Infrastructure" mode, Wireless Clients normally scan all Channels, looking for an Access Point. If more than one Access Point can be used, the one with the strongest signal is used. (This can only happen within an ESS.)
- If using "Ad-hoc" mode (no Access Point), all Wireless clients should be set to use the same Channel. However, most Wireless clients will still scan all Channels to see if there is an existing "Ad-hoc" group they can join.

WEP

WEP (Wired Equivalent Privacy) is a standard for encrypting data before it is transmitted.

This is desirable because it is impossible to prevent snoopers from receiving any data which is transmitted by your Wireless Clients. But if the data is encrypted, then it is meaningless unless the receiver can decrypt it.

If WEP is used, the Wireless Clients and the Access Point must have the same settings for each of the following:

WEP	Off, 64 Bit, 128 Bit
Key	For 64 Bit encryption, the Key value must match. For 128 Bit encryption, the Key value must match
WEP Authentication	Open System or Shared Key.

Wireless LAN Configuration

To allow Wireless Clients to use the Access Point, the Wireless Clients and the Access Point must use the same settings, as follows:

Mode	On client Wireless Clients, the mode must be set to "Infrastructure". (The Access Point is always in "Infrastructure" mode.)
SSID (ESSID)	Wireless Clients should use the same SSID (ESSID) as the Access Point they wish to connect to. Alternatively, the SSID can be set to "any" or null (blank) to allow connection to any Access Point.
WEP	The Wireless Clients and the Access Point must use the same settings for WEP (Off, 64 Bit, 128 Bit). WEP Key: If WEP is enabled, the Key must be the same on the Wireless Clients and the Access Point. WEP Authentication: If WEP is enabled, all Wireless Clients must use the same setting as the Access Point (either "Open System" or "Shared Key").

Appendix C

Specifications



Multi-Function WRT-413

Model	WRT-413
Dimensions	150 x 102 x 30 mm
Operating Temperature	0° C to 50° C
Storage Temperature	-10° C to 70° C
Network Protocol:	TCP/IP
Network Interface:	4 * 10/100BaseT (RJ45) LAN connection 1 * 10/100BaseT (RJ45) for WAN
LEDs	1 x POWER 1 x STATUS LAN: 4 x LNK/ACT, 4 x 100Mbps 1 x WAN 1 x WLAN
Power Adapter	12V DC, 1A External

Wireless Interface

Standards	Wireless: IEEE 802.11b / 802.11g
Frequency	2.4 to 2.4835GHz (Industrial Scientific Medical Band)
Channels	Maximum 14 Channels, depending on regulatory authorities
Radio Technology	Direct Sequence Spread Spectrum (DSSS)
Modulation	OFDM/BPSK/QPSK/CCK
Data Rate	802.11b: 11/5.5/2/1Mbps 802.11g: 54/48/36/24/18/12/9/6Mbps
Security	WEP 64/128Bit; WPA-PSK
Output Power	802.11b: 18 ~ 20dBm 802.11g: 11 ~ 14dBm
Antenna	1 x Detachable Dipole Antenna

Regulatory Approvals

CE Standards

This product complies with the 99/5/EEC directives, including the following safety and EMC standards:

- EN300328-2
- EN301489-1/-17
- EN60950

CE Marking Warning

This is a Class B product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.