


## VIP-320/VIP-280

### Firmware Upgrade Procedure:

Please download the latest firmware to a PC first, and browse to the **“Backup/Restore --> Configurations”** menu, and click on the **“Browse”** icon to select the file, once the firmware file is entered, please click on the **“Restore”** icon to proceed with the updating process.



After process completed, please click on the **“Reboot”** button below:



After loading the firmware files, it is suggested to load the factory default settings to activate the new configurations. Please press the RESET button on the rear panel over 8 seconds or until SYS LED begins to flash. When factory reset is completed, the Default LAN IP is <http://192.168.0.1> for factory.

### Hint

Never power off the VoIP router when restoring machine configuration file or upgrading the firmware, the machine will be damaged permanently.