

SIP Analog Telephony Adapter

**VIP-156 / 157 Series
Phone Book Configuration**



- **Phone Book for VoIP SIP ATA VIP-156 / VIP-157 Series**

- Phone Book Description:

The ATA can set **140** records of Phone Book, user can dial the **Name** record to make calls via **Phone Book** feature.

Phone Book Page:

Phone	Name	URL	Select
0	301	301@192.168.1.2	<input type="checkbox"/>
1	206	17476433364	<input type="checkbox"/>
2	202	192.168.1.2:5062	<input type="checkbox"/>
3			<input type="checkbox"/>

- **The Phone Book each field description**

Phone Book Page	It can select Page1 ~ Page 14 to look round Phone Book records. (The default is Page 1)
Phone	The record number from 0 ~ 139, it can set up 140 records in total.
Name	The name of Phone Book records, it only can input numerals.
URL	Fill in the outgoing number (Line Number) or IP address.
Select	To select this record.

- If you need to add a phone number into the Phone Book list, you need to input the **Position**, **Name**, and the **Phone** number field by **URL** type. When you finished a new phone list, just click the “**Add Phone**” button.

Add New Phone

Position:	<input type="text" value="0"/>	(0~139)
Name:	<input type="text" value="301"/>	
URL:	<input type="text" value="301@192.168.1.2"/>	
<input type="button" value="Add Phone"/>		<input type="button" value="Reset"/>

- If you want to delete a phone number, you can select the phone number you want to delete then click “**Delete Selected**” button.
- If you want to delete all phone numbers, you can click on the “**Delete All**” button.

Phone	Name	URL	Select
0	301	301@192.168.1.2	<input type="checkbox"/>
1	206	17476433364	<input type="checkbox"/>
2	202	192.168.1.2:5062	<input type="checkbox"/>
3			<input type="checkbox"/>
4			<input type="checkbox"/>
5			<input type="checkbox"/>
6			<input type="checkbox"/>
7			<input type="checkbox"/>
8			<input type="checkbox"/>
9			<input type="checkbox"/>

- **For Example**

- An ATA have add as previous page phone numbers into the PhoneBook of ATA.
- **Example 1 :**
The user can pickup the handset and dial the “**301**” to make the **P2P** call (**301@192.168.1.2**) .
- **Example 2 :**
Users pickup the handset and dial the “**206**” to make the **Proxy** call (**17476433364**) .
- **Example 3:**
Users pickup the handset and dial the “**202**” to make the **P2P** call (**192.168.0.2:5062**) .

ACTIVATING IP POWER

