![PLANET Networking & Communication]

How to register your ATAs to PLANET SIP Proxy Server (SIP-50)

Registration /   SIP-50   Registration /

Authentication   Authentication

SIP-50 IP Address: 192.168.0.50

- ATA A IP Address: 192.168.0.1   ■ ATA B IP Address: 192.168.0.2

  Line Number: 1001   Line Number: 2002

Device configurations on the ATA:

STEP 1:

Log in SIP-50 and create two testing accounts/password: **1001 / 123** (for ATA A), and **1002 / 123** (for ATA B) for the voice calls.

STEP 2:

Please log in ATA via web browser, browse to the **SIP setting** menu and select the **Domain Service** config menu. In the setting page, please insert the account/password information obtained from your service provider (in this sample, we're using PLANET SIP-50 as the SIP Proxy server for SIP account, call authentications), and then the sample configuration screen is shown below:

Service Domain Settings

You could set information of service domains in this page.

Realm 1 (Default)	
Active:	⊙ On ○ Off
Display Name:	1001
Line Number:	1001
Register Name:	planet
Register Password:	•••
Domain Server:	192.168.0.50
Proxy Server:	192.168.0.50
Outbound Proxy:	
Status:	Registered

STEP 3:

Repeat the same configuration steps on ATA B, and check the machine registration status, make sure the registrations are completed.

Test the scenario:

1. Pick up the telephone on ATA A
2. Press the keypad: **2002** shall be able to connect to the ATA B
3. Then the telephone set in ATA B should ring. Please repeat the same dialing steps on ATA B to establish the first voice communication from ATA A