

# Release Notes

## Release Notes

**Keywords:** Version information, version upgrade

**Abstract:** This document provides detailed version information and upgrade procedure for  
DIPC-B1211.6.18.C00031.220802/GIPC-B6110.5.13.C00031.220802/  
QIPC-R1201.30.42.C00068.220802/DIPC-B1209.6.13.C00031.220802.

**Acronym:**

Acronym	Full Name
IPC	IP Camera

---

---

# Content

<b>1 Version Information</b> .....	<b>3</b>
1.1 Version Number .....	3
1.2 Release History .....	3
1.3 Version Mapping Table .....	3
1.4 Feature and Change Description .....	5
<b>2 Version Upgrade Procedure</b> .....	<b>5</b>
2.1 Upgrade Overview .....	5
2.1.1 Version Upgrade Environment .....	5
2.2 Upgrade Procedure .....	6
2.2.1 Upgrade Through the Web .....	6

# 1 Version Information

## 1.1 Version Number

DIPC-B1211.6.18.C00031.220802

GIPC-B6110.5.13.C00031.220802

QIPC-R1201.30.42.C00068.220802

DIPC-B1209.6.13.C00031.220802

## 1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
DIPC-B1211.6.18.C00031.220802	DIPC-B1211.6.15.C00020.211210	2022-08-09	Improved release

Version No.	Basic Version No.	Released On	Remarks
GIPC-B6110.5.13.C00031.220802	GIPC-B6110.5.10.C00020.211210	2022-08-09	Improved release

Version No.	Basic Version No.	Released On	Remarks
QIPC-R1201.30.42.C00068.220802	QIPC-R1201.30.41.C00060.220523	2022-08-09	Improved release

Version No.	Basic Version No.	Released On	Remarks
DIPC-B1209.6.13.C00031.220802	DIPC-B1209.6.10.C00020.211214	2022-08-09	Improved release

## 1.3 Version Mapping Table

Table 2 Product models and corresponding versions

Product Series	IPC Series
Series	<b>IPC2124LR5</b> 、 <b>IPC672LR</b> 、 <b>IPC324LE</b> 、 <b>IPC3614LE</b> 、 <b>IPC672LR</b> 、 <b>IPC3632LB</b> <b>IPC322LB</b> 、 <b>IPC3612LB</b> 、 <b>IPC3532LB</b> 、 <b>IPC2122LB</b> 、 <b>IPC2322LB</b> 、 <b>C1L</b>
Models	<b>IPC2124LR5 Series:</b> IPC2124LR5-DUPF28M-F、IPC2124LR5-DUPF40M-F
	<b>IPC324LE Series:</b> IPC324LE-DSF28K、IPC324LE-DSF40K
	<b>IPC3614LE Series:</b> IPC3614LE-ADF28K、IPC3614LE-ADF40K
	<b>IPC672LR Series:</b> IPC672LR-AX4DUWK

	<b>IPC3632LB Series:</b> IPC3632LB-ADZK
	<b>IPC322LB Series:</b> IPC322LB-DSF28K、IPC322LB-DSF40K
	<b>IPC3612LB Series:</b> IPC3612LB-ADF28K、IPC3612LB-ADF40K
	<b>IPC3532LB Series:</b> IPC3532LB-DSZK
	<b>IPC2122LB Series:</b> IPC2122LB-DSF28KM、IPC2122LB-DSF40KM
	<b>IPC2122LB Series:</b> IPC2122LB-DSF28KM、IPC2122LB-DSF40KM
	<b>IPC2322LB Series:</b> IPC2322LB-DSZK
	<b>C1L Series:</b> C1L-2WN
Target file name	DIPC-B1211.6.18.C00031.220802.zip

Product Series	IPC Series
Series	<b>IPC2124SS 、 IPC2224SS 、 IPC324SS 、 IPC2324SS 、 IPC3234SS 、 IPC3634SS 、 IPC3614SS</b>
Models	<b>IPC2124SS Series:</b> IPC2124SS-ADF28KM、IPC2124SS-ADF40KM
	<b>IPC2224SS Series:</b> IPC2224SS-DF40K、IPC2224SS-DF60K
	<b>IPC324SS Series:</b> IPC324SS-DF28K、IPC324SS-DF40K
	<b>IPC2324SS Series:</b> IPC2324SS-DZK
	<b>IPC3234SS Series:</b> IPC3234SS-DZK
	<b>IPC3634SS Series:</b> IPC3634SS-ADZK
	<b>IPC3614SS Series:</b> IPC3614SS-ADF28KM、IPC3614SS-ADF40KM
Target file name	GIPC-B6110.5.13.C00031.220802.zip

Product Series	IPC Series
Series	<b>IPC562E 、 IPC3231ER 、 IPC3234SR 、 IPC2322EBR 、 IPC2324EBR 、 IPC262ER9 、 IPC262EFW 、 IPC3232ER3 、 IPC262EBR9</b>
Models	<b>IPC562E series:</b> IPC562E-DUG
	<b>IPC3231ER series:</b> IPC3231ER-DV
	<b>IPC3234SR series:</b> IPC3234SR-DV、IPC3234SR3-DVZ28
	<b>IPC2322EBR series:</b> IPC2322EBR-DPZ28
	<b>IPC2324EBR series:</b> IPC2324EBR-DPZ28、IPC2324EBR-DP、IPC2324EBR-DPZ28
	<b>IPC3232ER3 series:</b> IPC3232ER3-DUVZ、IPC3232ER3-DVZ28、IPC3232ER3-DUV IPC3232ER3-HDUVZ

	<b>IPC262ER9 series:</b> IPC262ER9-DUZ、IPC262ER9-X10DU
	<b>IPC262EFW series:</b> IPC262EFW-DUZ
	<b>IPC262EBR9series:</b> IPC262EBR9-HDUPZ
Target file name	QIPC-R1201.30.42.C00068.220802.zip

Product Series	IPC Series
Series	<b>IPC3613LR3、IPC323LR3、IPC322LR3、IPC3612LR3、IPC2123LR3、IPC2122LR5 IPC2A23LB、IPC2C22LE</b>
Models	<b>IPC3613LR3 series:</b> IPC3613LR3-APF28K-F、IPC3613LR3-APF40K-F IPC3613LR3-PF28-F、IPC3613LR3-PF40-F
	<b>IPC323LR3 series:</b> IPC323LR3-VSPF28-F、IPC323LR3-VSPF40-F
	<b>IPC322LR3 series:</b> IPC322LR3-UVSPF28-F、IPC322LR3-UVSPF40-F
	<b>IPC3612LR3 series:</b> IPC3612LR3-UPF28-F、IPC3612LR3-UPF40-F
	<b>IPC2123LR3 series:</b> IPC2123LR3-PF28M-F、IPC2123LR3-PF40M-F
	<b>IPC2122LR5 series:</b> IPC2122LR5-UPF28M-F、IPC2122LR5-UPF40M-F
	<b>IPC2A23LB series:</b> IPC2A23LB-F40K、IPC2A23LB-F60K
	<b>IPC2C22LE series:</b> IPC2C22LE-SF40-WL、IPC2C22LE-SF60-WL
Target file name	DIPC-B1209.6.13.C00031.220802.zip

## 1.4 Feature and Change Description

None.


## 2 Version Upgrade Procedure

### 2.1 Upgrade Overview

#### 2.1.1 Version Upgrade Environment

##### 1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

## 2.2 Upgrade Procedure

### 2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

<b>Firmware Upgrade</b>	
Upgrade File	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Upgrade"/> <input type="checkbox"/> Upgrade Boot Program
<b>Device Restart</b>	
<input type="button" value="Restart"/>	Restart the device.
<input type="checkbox"/> Enable Auto Restart	<input type="text" value="Each Day"/> <input type="text" value="02:00:00"/> <input type="button" value="OK"/>
<b>Config Management</b>	
<input type="button" value="Default"/>	Keep current network and user settings and restore other settings to defaults.
Importing	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Import"/>
Exporting	<input type="text" value="C:\Users\Desktop\lftp"/> <input type="button" value="Browse..."/> <input type="button" value="Export"/>
<b>Diagnosis Info</b>	
Storage Path	<input type="text" value="C:\Users\MyLocalFiles\Debug\"/> <input type="button" value="Browse..."/> <input type="button" value="Download"/>

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC\_Q1201-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.