# DPC-D250 and D268 update via SD card

Main unit

1. Format SD card by computer, then copy the firmware "xxxx.bin"(DT608IAP.bin）(can't change the name of firmware) to the ROOT DIRECTORY of this SD card
2. Power on DPC-D250 or D268 , insert the SD card into the slot, with a "Beep" DT608 will start to update and LED_NAME will turn off. At last LED-NAME will be on again that means update is successful.