


## **EHDMIC11B-TR**

# **HDbitT HDMI Extender**

**User manual** 



#### INTRODUCTION

HDMI HDbitT extender, takes the advantages of the latest transmission technology - HDbitT, extends your HDMI video/audio with the resolution up to 1080p 60Hz up to 120m(394 feet) via single network cable.

## **Important Safety instructions:**

- Do not mix up the HDMI EXTENDER sender and HDMI EXTENDER receiver.
- 2. Do not plug-in/out the cables ,when it is in using.
- 3. Use DC 5V power supply only. Make sure the specification matched if using 3rd party DC adapters.

## Package Contents



HDMI EXTENDER sender TX ×1pcs



HDMI EXTENDER receiver Rx ×1pcs



DC5V/1A ×2pcs



User Manual ×1pcs


Note: above accessory contents is regular package for a kit. If buy HDMI extender TX or HDMI extender RX separately, the package contents would be different.

## • Installation Requirements

- HDMI source device(computer graphics card, DVD,PS3, HD monitoring equipment etc).
- 2. HDMI display device like SDTV, HDTV, projector with HDMI port.
- 3. Network cables: UTP/STP Cat5e/6 network cables, which following the standard of IEEE-568B.

## • Panel Description

## 1. HDMI EXTENDER TX (Sender)




- ① Power input ( DC5V )
- ② HDMI signal input




- ③ RJ45 signal output
- ④ Reset

#### 2. HDMI EXTENDER RX(Receiver)



- ① Power input ( DC5V )
- ② HDMI signal output



- ③ RJ45 signal input
- 4 Reset

#### • Installation Procedures

#### 1. How to make a Cat5e/6 network cable

Follow the stanard of IEEE-568B:

1-Orange/white 4-Blue 7-Brown/white


2-Orange 5-Blue/white 8-Brown

3-Green/white 6-Green




#### 2. Connections


**2.1 Point to Point connection:** Up to 120 meters transmission distance over single CAT6 (High quality cable can reach 150 meters).



**2.2 Router Connection:** By using network router/repeater, realize unlimited extension.



**2.3 One-to-many Connection:** By using network router/switch , one sender to several receivers, realize extender & splitter function.



Note: Gigabit (1000Mbps) switcher is recommended in LAN transmission.

#### • FAO

- **Q**: TV display "Waiting for connection" on the right corner?
- **A** : Please check if the power supply of TX (Sender) and switcher (if used) is connected, and make sure connecting cable is firmly.
- **Q**: TV display "Please check the TX input signal"?
- A: 1) please check if there is a HDMI signal input of TX.
  - Try to connect the signal source directly to display device to see if there is singal output from source device or change the signal source, HDMI cable and try again.
- Q: Display not fluent, not stable?
- A: 1) Please check the cable length between the TX to switch, the switch to the RX and the connection between each level is within the required range.
  - 2) Click the "reset" button on the TX/RX front panel, reset and reconnect.

## Specification

Items	Specifications
HDMI Signal	Compatible with HDCP
transport protocol	HDbitT
Support resolutions	480i@60Hz, 480p@60Hz, 576i@50Hz, 576p@50Hz, 720p@50/60Hz, 1080i@50/60Hz, 1080p@50/60Hz
Network Cable	UTP/STP Cat5/5e/6
Transmission distance	Up to 120 meters transmission distance for 1080p 60Hz Full HD over single CAT6. CAT5 80m/CAT5E 100m/CAT6 120m
Working Temperature	0°C ~ 60°C
Power Supply	DC5V/1A
Power Consumption	TX: 3.5W; RX: 3W
Dimensions	110(W) x 58(D) x 26(H)mm *2PCS
Weight	TX: 125g RX: 120g
Color	Black

#### Disclaimer

The product name and brand name may be registered trademark of related manufacturers. TM and ® may be omitted on the user manual. The pictures on the user manual are just for reference, and there may be some slight difference with the real products.

We reserve the rights to make changes without further notice to a product or system described herein to improve reliability, function or design.