WM_Client User's Manual



Product introduction_____

Product introduction

[Features]

- With this program installed on PDA, user can monitor the images on megapixel network camera over network.
- Wireless networks are easy to use without restrictions in place.
- It provides easy connection and site(camera) registration.
- You can control the system efficiently by ID and password with different authority.
- It can capture & save a still image.
- Full screen mode available.

Contents

Chapter 1. Program Installation

1.1 PDA specification 1.2 Program installation	3 3
Chapter 2. For the start of PDA Viewer	4
2.1 Site Registration, edit, delete(Network Camera Registration)	7

0

1.1 PDA Specification

	Minimum Specifications	Recommended Specifications
CPU	Strong Arm	
O/S	Pocket PC 2003	Windows mobile 6.0 Classic
Resolution	320 × 240	640 x 480

1.2 Program installation

- 1. Copy the cab file into the PC from the install CD.
 - 1.1 Use the AcitveSync program then copy to PDA or
 - 1.2 Connect the memory card of PDA to user's PC then copy the file.
- 2. Click "cab file" and start the installation.

3

Chapter 2. For the start of PDA viewer -

Start program by clicking Start \rightarrow Program \rightarrow WM_Client icon in order.



[Picture 2-1] Monitoring screen

STREAMMORE	J	Connect to JPEG stream
		Connect to MPEG4 stream
		Connect
		Select site to connect
		Disconnect
		Full Screen
		Site registration
		Capture

[Button explain]

NAME site-1	ADDRESS 192.168.0.203	MODIF
rand site-2	61.37.240.220 192.168.0.202	DELETE
ID: PW:	root	COMMED
F 88 -	MPEG4	CANCEL

<Camera list management> User can add, modify or delete the site.

[Picture 2-2] Camera list management screen

[Button explain]

ADD	Site adding
MODIFY	Site editing
DELETE	Site deletion
CONNECT	Connect site
CANCEL	Close this menu

Chapter 2. For the start of PDA viewer -

2.1 Add, edit of site (Network camera registration)

ADDRESS :			
PORT : ID/PW-	9000		
ID :			
PW : IP/PV	N Save	~	
a	ONFIRM	- X4	ICEL
	2141 1144	CVII	

Input the name address, port, ID and password.

[picture 2-4] Pop-up menu of site addition or deletion

[Button explain]

CONFIRM	Save and exit
CANCEL	Cancel and close

•Please read this manual carefully before installing and using the product and preserve it for reference purposes.

•This specification is subject to change without any prior notice to improve the quality.