



## **CARDUSB2 User Manual**

**Revision 1.0  
Tuesday, May 31, 2011**

## CONTENTS

1	Revision History .....	3
2	Introduction .....	4
3	Scope .....	4
4	Attachment of the CARDUSB2 to USB port of PC.....	4
4.1	CARDUSB2 Camera View .....	4
4.2	CARDUSB2 to PC HOST interconnecting cable view.....	5
4.3	Attachment of CARDUSB2 to PC HOST interconnecting cable .....	5
4.4	Attachment of CARDUSB2 to PC .....	6
5	Software Installation .....	7
5.1	Installation AMCAP2.....	7
5.2	Contrast /Brightness Adjustments .....	7

# CARDUSB2

## 1 Revision History

Rev No	Date	Major Changes	
1.0	May 31, 2011	Initial Draft Version	

## 2 Introduction

This document is intended to provide details of the CARDUSB2 camera sensor.

## 3 Scope

The scope of this document is limited to the following major goals

General instruction to start using the CARDUSB2.


## 4 Attachment of the CARDUSB2 to USB port of PC

The following section walks through the steps involved in fixing the CARDUSB2

### 4.1 CARDUSB2 Camera View




## 4.2 CARDUSB2 to PC HOST interconnecting cable view




## 4.3 Attachment of CARDUSB2 to PC HOST interconnecting cable

Step1: Place the cable to connector as shown in this fig.




Step2: Place the cable to connector as shown in fig.

Press gently on connector as indicated in the picture.



#### 4.4 Attachment of CARDUSB2 to PC





## 5 Software Installation

### 5.1 Installation AMCAP2

1. Install the AMCAP2.EXE kept under the directory sample application.

### 5.2 Contrast /Brightness Adjustments

1. Open AMCap
2. Click Options /Video Capture Filter
3. Start adjusts Bar of Brightness or Contrast to the proper one.

