

Trademarks

Copyright © PLANET Technology Corp. 2002. Contents subject to revision without prior notice. PLANET is a registered trademark of PLANET Technology Corp. All other trademarks belong to their respective owners.

Disclaimer

PLANET Technology does not warrant that the hardware will work properly in all environments and applications, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose.

PLANET has made every effort to ensure that this User's Manual is accurate; PLANET disclaims liability for any inaccuracies or omissions that may have occurred.

Information in this User's Manual is subject to change without notice and does not represent a commitment on the part of PLANET. PLANET assumes no responsibility for any inaccuracies that may be contained in this User's Manual. PLANET makes no commitment to update or keep current the information in this User's Manual, and reserves the right to make improvements to this User's Manual and/or to the products described in this User's Manual, at any time without notice.

If you find information in this manual that is incorrect, misleading, or incomplete, we would appreciate your comments and suggestions.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference at his own expense.

PLANET Smart Switch series

CE Mark Warning

This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Revision

PLANET Switch User's Manual FOR MODELS: FGSW-2402S Part No.: EM-FG24V1

FGSW-2402S User's Manual

TABLE OF CONTENTS

1. INTRODUCTION	1
1.1 CHECKLIST1.2 ABOUT THE SWITCH1.3 FEATURES1.4 SPECIFICATIONS	1 1 2 3
2. HARDWARE DESCRIPTION	7
 2.1 FRONT PANEL 2.1.1 LED indictor for whole switch 2.1.2 LED indictor for 10/100Base-TX port 2.1.3 LED indictor for modules 2.1.4 Reset button 2.2 REAR PANEL 2.3 HARDWARE INSTALLATION 2.3.1 Switch Placement 2.3.2 Network Installation 	
3.CONFIGURATION	15
 3.1 CONNECT TO PC	
4. SWITCH OPERATION	27
 4.1 Address Table 4.2 Learning 4.3 Forwarding & Filtering 4.4 Store-and-Forward 4.5 Auto-Negotiation 	
4 PLANET Smart Sw	vitch series

APPENDIX A			3
A.1 SWITCH'S RJ A.2 10/100MBPS A.3 RJ-45 CABLE	I-45 PIN ASSIGNME 5, 10/100Base-TX. 5 PIN ASSIGNMENT	NTS	3 3 3



1. INTRODUCTION

1.1 Checklist

Check the contents of your package for following parts:

- FGSW-2402S.
- User's manual.
- Power cord.
- 19" rack mount brackets.
- RS-232 cable.

If any of these pieces are missing or damaged, please contact your dealer immediately. If possible, retain the carton including the original packing material, and use them against to repack the product in case there is a need to return it to us for repairing.

1.2 About the Switch

With two open slots available for fiber or copper Gigabit modules, the FGSW-2402S can accelerate your Cat5 backbone to 10 times the performance of existing 100 Megabit without re-wiring your cabling infrastructure. The optional Gigabit modules can be Gigabit fiber-optic, (SX or LX) and also Fast Ethernet fiber-optic up to 10 kilometers away. Powered by a non-blocking 9.6Gbps backplane, the FGSW-2402S simplifies the task of upgrading your LAN to cater for increased bandwidth demand.

Equipped with a console interface the Gigabit Smart Switch can be programmed for basic switch management functions such as bandwidth provision, port status configuration, VLAN parameters, port-trunking, and port monitoring.

The switch is suitable for the following applications:

Workgroup switch:

By installing a Gigabit copper NIC such as PLANET's ENW-9601T (32/64-bit PCI Gigabit Ethernet Adapter), upgrading your workgroups or servers from Ethernet or Fast Ethernet to Gigabit Ethernet is simple, ensuring compatibility for current and future networks and protecting your network investment.

FGSW-2402S User's Manual

Department Switch:

With a proven Gigabit Ethernet Interface, there has never been a better time to connect your workgroups to the backbone using the 4-pair CAT 5/5e UTP cables that already exist in your building. IEEE802.3x flow-control is enabled to ensure high performance Gigabit trunking (up to 4Gbps bandwidth) without any loss of network packets. The choice of Gigabit fiber optic modules includes LX to extend network reach where required.

MTU Switch:

In an MTU/MDU application, the advanced functionality of the FGSW-2402S eliminates traditional problems associated with the use of Ethernet. Users can be segregated with advanced VLAN functionality and the unique 'MTU switch mode' to enhance security, and bandwidth managed with tiered bandwidth provision and control using configurable 9 levels of upstream/downstream restriction. This, couple with the flexible 100FX, 1000SX/LX/T module options make the FGSW-2402S one of the best and most cost-effective MTU switch solutions for Multi-tenant service providers.

1.3 Features

- Complies with the IEEE802.3, IEEE802.3u, IEEE802.3z and IEEE802.3ab Gigabit Ethernet standard
- 24 (10/100 Mbps), 2-open slots (10/100/1000Mbps) Ethernet Smart Switch
- 9.6 Gbps switching fabric, true non-blocking switch architecture, wire-speed forwarding
- 10Base-T/100Base-TX ports provide auto-negotiation for speed and duplex mode selection
- Gigabit Ethernet Module slot support for 10/100/1000Mbps copper interface, 1000Base-SX/LX or 100Base-FX optic interface.
- Prevents packet loss with back pressure (half-duplex) and 802.3x PAUSE frame flow control (full-duplex)
- High performance Store and forward architecture, broadcast storm control, runt/CRC filtering eliminates erroneous packets to optimize the network bandwidth

PLANET Switch series



Switch Processing Scheme	Store-and-forward
Address Table	8K entries, auto learning/ageing
Queue Buffer	6Mbit shared buffer
Flow Control	Back pressure for half duplex, IEEE 802.3x for fu duplex
Packet Control	Runt & CRC filtering, Broadcast storm control
	Power, Ready
LED indicators	LNK/ACT, 100, FDX/COL for each port
	1000,100,10(FX), FDX/COL, TX, RX for modules
Switch Management	
System management	Console port
Aging Time	1~999 seconds, disable
Broadcast Storm Control	Disable, 6%, 20%
Port Configuration	Enable/Disable port
	10/100/Full/Half/Auto-negotiation
	Enable/Disable Flow Control
	Nine levels (3%, 6%, 9%, 12%, 20%, 40%, 60%, 80%, Full Speed) for transmitting (TX) and receiving (RX) rate
Port Statistics	Show each port's statistics data
VLAN	MTU VLAN Supported (1~25 uplink to 26, or 1~12 uplink to 25 and 13~24 uplink to 26)
	Up to 8 port-based VLAN groups
Link Aggregation	4 trunks support per switch
	Up to 8 10/100 ports or 2 Gigabit ports per trunk
Port Mirroring	Mirroring single port's traffic

EmissionsFCC Class A, VCCI Class A, CISPR 22 Class ASafetyCSA/NRTL (C.22.2.950, UL1950), TÜV/GS (EN60950)ImmunityEN60555-2 Class A, EN60555-3TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	EmissionsFCC Class A, VCCI Class A, CISPR 22 Class ASafetyCSA/NRTL (C.22.2.950, UL1950), TÜV/GS (EN60950)ImmunityEN60555-2 Class A, EN60555-3TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)		EN50082-1, IEC 1000-4-2/3/4/6
SafetyCSA/NRTL (C.22.2.950, UL1950), TÜV/GS (EN60950)ImmunityEN60555-2 Class A, EN60555-3TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	SafetyCSA/NRTL (C.22.2.950, UL1950), TÜV/GS (EN60950)ImmunityEN60555-2 Class A, EN60555-3TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Emissions	FCC Class A, VCCI Class A, CISPR 22 Class A
ImmunityEN60555-2 Class A, EN60555-3TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	ImmunityEN60555-2 Class A, EN60555-3TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Safety	CSA/NRTL (C.22.2.950, UL1950), TÜV/GS (EN60950)
TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	TemperatureStandard Operating: 0~50°C (32~122°F) Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Immunity	EN60555-2 Class A, EN60555-3
Storage -40~70°C (-40~158°F)Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Storage -40~70°C (-40~158°F) Humidity 5% to 95% (Non-condensing) Standards IEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Temperature	Standard Operating: 0~50°C (32~122°F)
Humidity5% to 95% (Non-condensing)StandardsIEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Humidity 5% to 95% (Non-condensing) Standards IEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)		Storage -40~70°C (-40~158°F)
Standards IEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Standards IEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)	Humidity	5% to 95% (Non-condensing)
		Standards	IEEE 802.3 (Ethernet), IEEE 802.3u (Fast Ethernet), IEEE 802.3ab, IEEE802.3z (Gigabit Ethernet), IEEE8023x (flow control)

FGSW-2402S User's Manual





2.1.1 LED indictor for whole switch

There are two LEDs for whole switch system.

PWR	Green	Lit: power on
READY	Green	Lit: CPU initial completed

2.1.2 LED indictor for 10/100Base-TX port

Each 10/100Base-TX port has three LED indicators.

LNK/ACT	Green	Lit: port has established a valid network connection.
		Blink: traffic is passing through the port
100Mbps	Green	Lit: connected on 100M speed.
		Lit off: connected on 10M speed
FDX/		Lit: Full-Duplex
COL	Yellow	Blink: Half-Duplex/ Collision
		Off: Half-duplex or not connected

2.1.3 LED indictor for modules

There are six LED indicators for modules of FGSW-2402S. These modules have different LED definition when different module installed.

SGSW-A1GT 10/100/1000Base-T modules

1000	Green	Lit: indicate link status and connected on 1000Mbps
100	Green	Lit: indicate link status and connected on 100Mbps
10 (FX)	Green	Lit: indicate link status and connected on 10Mbps
FDX/CO	L Green	Lit: Full-Duplex
		Blink: Half-Duplex/ Collision
		Off: Half-duplex or not connected
ΤХ	Green	Lit: indicate data transmitting status
RX	Green	Lit: indicate data receiving status
		PLANET Switch serie



FGSW-2402S User's Manual

2.3 Hardware Installation

2.3.1 Switch Placement

This section describes how to install your FGSW-2402S Gigabit /Fast Ethernet Switch and make connections to the switch. Please read the following topics and perform the procedures in the order being presented.

PLANET FGSW-2402S Gigabit /Fast Ethernet Switch do not need software configuration. To install your FGSW-2402S on a desktop or shelf, simply complete the following steps.

2.3.1.1 Desktop or Shelf Mounting

To install a FGSW-2402S on a desktop or shelf, simply complete the following steps:

- Step1: Attach the rubber feet to the recessed areas on the bottom of the switch.
- Step2: Place the FGSW-2402S on a desktop or shelf near an AC power source.
- Step3: Keep enough ventilation space between the switch and the surrounding objects

Note: When choosing a location, please keep in mind the environmental restrictions discussed in Chapter 1.4, Specification.

Step4: Connect your FGSW-2402S to network devices

- **A.** Connect one end of a standard network cable to the 10/100 RJ-45 ports on the front of the FGSW-2402S.
- **B.** Connect the other end of the cable to the network devices such as printer servers, workstations or routers...etc.

Note: Connection to the Switch requires UTP Category 5 network cabling with RJ-45 tips. For more information, please see the Cabling Specification in Chapter 1.4, Specification and Appendix.

Step5: Supply power to the Switch.

- A. Connect one end of the power cable to the FGSW-2402S
- **B.** Connect the power plug of the power cable to a standard wall outlet.
- 10

PLANET Switch series









	3.CONFIGURATION
3.1 Coni	nect to PC
RS-232	2 serial cable
Prej con side	pare a RS-232 serial cable. Attach the 9-pin female nector to the male connector on the switch. Plug the othe e of this cable to your PC.
Hyper	Terminal
Pr	ert Settings
	Advanced Bestore Defaults OK Cancel Apply



3.3 Submenu: (1) Device Configuration

(1)			
5.8.1	Aging Times	[300] sec.	
(8)	Repadcast Storm Preventices ULAN Hode Confidurations	(280) Port Rased ULAN)	
(4)	ITTU-TOU Per-Port VLAN	(One Uplink)	

Entry: select "1" from main menu.

Device Configuration:

- (1) **Aging Time:** allow to set up aging cycle time, the maximum time is 999 sec.
- (2) **Broadcast Storm Prevention:** allow limit per port incoming rate of broadcast traffic.
- (3) VLAN Mode Configuration: provide two methods to assign VLAN.

Port Based VLAN: 8 VLAN groups can be assigned. **MTU/MDU Per-Port VLAN:** divide 1-24 port into different VLAN group

(4) MTU/MDU Per-Port VLAN: provide two different VLAN choices: One Uplink (MTU): port 1-25 will be assign to different VLAN groups and uplink to port 26.

Two Uplink (MDU): it will assign port 1-12 as different VLAN groups and uplink to port 25, assign port 13-24 as different groups and uplink to port 26

FGSW-2402S User's Manual

3.4 Submenu :(2) Port Configuration

🌯 FG	ssw-	2402S - Hyp	erTermina	sl				_ 0	
File	Edit	View Call	Transfer	Help	1				
	2 🗩	3 08	67						
		,	- Port Cost	4023 S	tart Su	ttch			1-
	Broup	ID: A							
	Post	Operational	Link	Partit	loned	Duples	Speed		
92	111	Xes .		No		B&L	1997		
18	15	200		10		201	10.00		
18	12	Cont.	0E	100		EXEE	0.00		
18	12	Vers Vers	ue Ue	na No		Ett	1990		
138	招招	200	0g	100		88F	28		
1.02	(12)	Ves	06	hã		FOCE	1084		
L	101000	I CALMENT COME							-
<u> </u>	(F)FR6	SP CHUMEAT TABLE	AU	_					1-
Conn	ected	0:08:10	Auto deter	et 👘	19200	8-N-1	SCROLL	CAPS	

Entry: Select "2" from Main Menu.

Purpose: Media Speed Control on each port.

Default: All ports assigned to one VLAN.

Type "N" to next page.

Type "**port number**" to enter the port configuration of each port. The following screen is shown as below:

	PLANET FESH-24225	Shart Switch	
Port Hunbers 1	- Poet Contrage	Fastion -	
Operational Status Lisk Status Bato Partition: Deplemi Speeds	12 Ven Up 190 FULL 19991		
1) Edwin, State: () 2) Speed & Duplew: () 3) Flow Control: () 4) Is Bandwidth Prov	hable) sto) hable) slosi (Euli Speed)		
ISI Ri Banduidth Provi	sioni (Fill Speed)		
(P)PREV PORT (NIN	DAT FORT COLEXIT_		

Port Configuration:

- (1) Admin. State: provide disable or enable specific port.
- (2) **Speed & Duplex:** allow to set various speed-duplex mode.
- (3) Flow Control: provide disable or enable flow control.
- (4) **Tx Bandwidth Provision:** provide 9 levels: 3%, 6%,9%,12%, 20%,40%,60%,80%, full-speed for transmitting(TX).
- (5) **Rx Bandwidth Provision:** provide 9 levels: 3%, 6%,9%,12%, 20%,40%,60%,80%, full-speed for receiving(RX).

3.5 Submenu: (3) Port Statistics

FGSW-2402S - Hy	perTerminal			
File Edit View Cal	Transfer He	lp .		
DI# 98 019	12			
	PLAYET FISH-24825	Snart Switch		
Dana IIIn A	- Port Statist	ics -		
Frances, Rai () Seter, Nar () Broadcast Elvi () Briticaat Elvi () Strances Setti () Seter Setti () Districtaat Elvi () Districtaat () Distric				
ISISELECT (R)RESET	(PIPREV ININEXT	DOEXIT		
Connected 0:12:55	Auto detect	19200 8-N-1	SCROLL	CAPS
Port Statistics : Frames Rx: Fram priority levels.	ne count on red	ceived good ι	unicast fra	mes of all
Bytes Rx: Octets level 1.	count on rece	ived good un	icast frame	es of priorit
Broadcast Rx: Fipriority.	ame count on	received goo	d broadca	st frames o
Multicast Rx: Fra	ame count on r	eceived good	d multicast	frames of a

FGSW-2402S User's Manual



FGSW-2402S - F	typerTerminal			_ 🗆 🗙
File Edit View C	all Transfer H	elp		
	PLAYET FISH-2422	i Shart Switch		14
Port Base VLRM Enabled	Index 1 130 1 3000000000000000000000000000000000000	Port Rep 100000000 100000000	25	
COEXIT				
Connected 0:16:32	Auto detect	19200 8-N-1	SCROLL	CAPS
Entry: Select "4 Purpose: Port-b Default: If you Configuration>,	" from Main Mo based VLAN se select < MTU/ This configura	enu. elect. /MDU Per-Por tion will not wo	t VLAN > ork	From <de< th=""></de<>
Entry: Select "4 Purpose: Port-t Default: If you Configuration>, Type "VLAN group thro VLAN group thro	" from Main Me based VLAN se select < MTU/ This configura bugh number" bugh the space	enu. elect. /MDU Per-Por tion will not wo to add VLAN i key. The scre	t VLAN > ork member po een is shov	From <de ort on each vn as belov</de
Entry: Select "4 Purpose: Port-t Default: If you Configuration>, Type "VLAN group VLAN group throw COSW-2402S - T File Edt View C	" from Main Me based VLAN se select < MTU/ This configura bup number " bugh the space typer ferminal at Transfer H	enu. elect. /MDU Per-Por tion will not wo to add VLAN e key. The scre	t VLAN > ork member po een is shov	From <de ort on each vn as belov</de
Entry: Select "4 Purpose: Port-b Default: If you Configuration>, Type "VLAN group throw VLAN group throw Color Color Color Color File Edd View Color	" from Main Mo based VLAN se select < MTU/ This configuration ough the space typer ferminal fransfer H	enu. elect. /MDU Per-Por tion will not wo to add VLAN to key. The scre	t VLAN > ork member po een is shov	From <de ort on each vn as belov</de
Entry: Select "4 Purpose: Port-to Default: If you Configuration>, Type "VLAN group thro VLAN group thro VLAN group thro CLAN group thro File Edit View CLAN File Edit View CLAN File Edit View CLAN	" from Main Me based VLAN se select < MTU/ This configura oup number " ough the space	enu. elect. /MDU Per-Por tion will not wo to add VLAN i e key. The scre be	t VLAN > ork member po een is shov	From <de< td=""></de<>
Entry: Select "4 Purpose: Port-b Default: If you Configuration>, Type "VLAN group thro VLAN group thro VLAN group thro Configurations, Type "VLAN	" from Main Me pased VLAN se select < MTU/ This configurar ough the space	enu. elect. /MDU Per-Por tion will not wo to add VLAN i e key. The scree be	t VLAN > ork member po een is shov	From <de< td=""></de<>

FGSW-2402S	- Hyp	erTerminal			- 🗆 ×
hie Edit View No≳l an I⊛l ⊮	Call Isol	Transfer Hel	p		
	민민	HALL FIGH-24825	Shart Suitch		1.
	Grosp	- Trunk Configur- Appresented Port	ation -		_
	1	(Disable)			
	2	<pre>(Disable)</pre>			
	4	(Disable)			
COEXIT		(1	Income Inco	
connected 0:17:50		Auto detect	19200 8-N-1	JSCROLL J C A	PS 📝
Entry: Select	"5" fr	om Main Mer	าน.		
Default: 4 Tru	ınk gi	roups are dis	able.		
Purpose: Tru	nk Co	onfiguration			
4 trunk groups	s opti	on shown as	below:		
Group1 : (0)D	isable	e (1)<1,5> (2))<1,2,5,6> (3)	<1,2,3,4,5,6,	7,8>:
Group2 : (0)D	isabl	e (1)<9,13> (2)<9,10,13,14	1>	
(3)<	9,10,	11,12,13,14,	15,16>:		
Group3 : (0)E)isabl	e (1)<17.21>	(2)<17.18.21	.22>	
(3)<	17.18	3.19.20.21 22	2.23.24>:		
Groun4 · (0))isahl	e (1)<25 265	-,_ v,_ .r .		
C. CupT . (0)D	15001	0 (1)~20,202			



File Eart	View Call Transfer Help
00 0	3 <u>08</u> m
	PLNET FOOD-24029 Shart Suitch
	11)Factory Defeelt Setting 12)Reset_
(2)60	·
Connected	0.22-23 Auto detect 19200 8-N-1 SCROLL CAPS
Entry: Se Purpose:	lect "7" from Main Menu. (1) Factory Default Setting: reset the default setting value
Entry: Se Purpose:	 lect "7" from Main Menu. (1) Factory Default Setting: reset the default setting value the Switch. (2) Reset: provide reboot the Switch.
Entry: Se Purpose:	 lect "7" from Main Menu. (1) Factory Default Setting: reset the default setting value the Switch. (2) Reset: provide reboot the Switch.
Entry: Se Purpose:	 lect "7" from Main Menu. (1) Factory Default Setting: reset the default setting value the Switch. (2) Reset: provide reboot the Switch.
Entry: Se Purpose:	 lect "7" from Main Menu. (1) Factory Default Setting: reset the default setting value the Switch. (2) Reset: provide reboot the Switch.
Entry: Se Purpose:	 lect "7" from Main Menu. (1) Factory Default Setting: reset the default setting value the Switch. (2) Reset: provide reboot the Switch.

FGSW-240	28 - HyperTerminal	telo	
		юр	
Barre	PLANET FIGUR-2485 - Password Password_planet (Nplanet	S Swart Sultch	
Save Press ana	DK key to esit		
Connected 0:3	7:58 Auto detect	19200 8-N-1 SCROLL	CAPS
Entry: Se Purpose	elect "8" from Main Main Main Main Main Main Main Main	Menu. e password. The defau	ult password
Entry: Se Purpose	elect "8" from Main N : User can change " admin", if you wa menu , the maxim	Menu. e password. The defau ant to change it , select in rum length is 10 charact	ult password tem 8 from ma ers.
Entry: Se Purpose	elect "8" from Main N : User can change " admin", if you wa menu , the maxim	Menu. e password. The defai ant to change it , select in num length is 10 charact	ult password tem 8 from ma ers.
Entry: Se Purpose	elect "8" from Main M : User can change " admin", if you wa menu , the maxim	Menu. e password. The defar ant to change it , select i num length is 10 charact	ult password tem 8 from ma ers.
Entry: Se Purpose	elect "8" from Main N : User can change " admin", if you wa menu , the maxim	Menu. e password. The defar ant to change it , select i num length is 10 charact	ult password tem 8 from ma ters.



4. SWITCH OPERATION

4.1 Address Table

The Switch is implemented with an address table. This address table composed of many entries. Each entry is used to store the address information of some node in network, including MAC address, port no, etc. This information comes from the learning process of Ethernet Switch.

4.2 Learning

When one packet comes in from any port, the Switch will record the source address, port no. and the other related information in address table. This information will be used to decide either forwarding or filtering for future packets.

4.3 Forwarding & Filtering

When one packet comes from some port of the Ethernet Switching, it will also check the destination address besides the source address learning. The Ethernet Switching will lookup the address-table for the destination address. If not found, this packet will be forwarded to all the other ports except the port which this packet comes in. And these ports will transmit this packet to the network it connected. If found, and the destination address is located at different port from this packet comes in, the Ethernet Switching will forward this packet to the port where this destination address is located according to the information from address table. But, if the destination address is located at the same port with this packet comes in, then this packet will be filtered. Thereby increasing the network throughput and availability.

4.4 Store-and-Forward

Store-and-Forward is one type of packet-forwarding techniques. A Store-and Forward Ethernet Switching stores the incoming frame in an internal buffer, do the complete error checking before transmission. Therefore, no error packets occurrence, it is the best choice when a network needs efficiency and stability.

The Ethernet Switch scans the destination address from the packet-header, searches the routing table provided for the incoming port and forwards the packet, only if required. The fast forwarding

FGSW-2402S User's Manual

makes the switch attractive for connecting servers directly to the network, thereby increasing throughput and availability. However, the switch is most commonly used to segment existing hubs, which nearly always improves overall performance. A Ethernet Switching can be easily configured in any Ethernet network environment to significantly boost bandwidth using conventional cabling and adapters.

Due to the learning function of the Ethernet switching, the source address and corresponding port number of each incoming and outgoing packet are stored in a routing table. This information is subsequently used to filter packets whose destination address is on the same segment as the source address. This confines network traffic to its respective domain, reducing the overall load on the network.

The Switch performs "Store and forward" therefore, no error packets occur. More reliably, it reduces the re-transmission rate. No packet loss will occur.

4.5 Auto-Negotiation

The STP ports on the Switch have built-in "Auto-negotiation". This technology automatically sets the best possible bandwidth when a connection is established with another network device (usually at Power On or Reset). This is done by detect the modes and speeds at the second of both device is connected and capable of, Both 10Base-T and 100Base-TX devices can connect with the port in either Half- or Full-Duplex mode. 1000Base-T and 1000Base-SX can only connected in Full-duplex mode.

PLANET Switch series





APPENDIX A

A.1 Switch's RJ-45 Pin Assignments

1000Mbps, 1000Base T

Contact	MDI	MDI-X
1	BI_DA+	BI_DB+
2	BI_DA-	BI_DB-
3	BI_DB+	BI_DA+
4	BI_DC+	BI_DD+
5	BI_DC-	BI_DD-
6	BI_DB-	BI_DA-
7	BI_DD+	BI_DC+
8	BI_DD-	BI_DC-

Implicit implementation of the crossover function within a twisted-pair cable, or at a wiring panel, while not expressly forbidden, is beyond the scope of this standard.

A.2 10/100Mbps, 10/100Base-TX

Contact	MDI	MDI-X
1	TX+	RX+
2	TX-	RX-
3	RX+	TX+
6	RX-	TX-

FGSW-2402S User's Manual



