

How to register your VIP-154T to PLANET SIP Proxy Server (SIP-50)



■ VIP-154T IP Address: 192.168.0.1 ■ VIP-154T IP Address: 192.168.0.2

Line Number: 1001 Line Number: 2002

Machine configuration on the VIP-154T:

STEP 1:

Log in SIP-50 and create two testing accounts/password: 1001/123 (for VIP-154T A), and 1002/123(for VIP-154T B) for the voice calls.


STEP 2:

Please log in VIP-154T A via web browser, browse to the **SIP setting** menu and select the **Domain Service** config menu. In the setting page, please insert the account/password information obtained from your service provider (in this sample, we're using PLANET SIP-50 as the SIP Proxy server for SIP account, call authentications), and then the sample configuration screen is shown below:



Service Domain Settings

You could set information of service domains in this page.



STEP 3:

Repeat the same configuration steps on VIP-154T B, and check the machine registration status, make sure the registrations are completed.

Test the scenario:

To verify the VoIP communication, you may make calls from SIP client (VIP-154T A) 1001 to the number 1002 (VIP-154T B) or reversely make calls from SIP client (VIP-154T B) 1002 to the number 1001 (VIP-154T A)

