



1. Parts and Functions




2. Terminal Descriptions




- **Lock Control Jumper:** To select the lock type: see 5.2.1 , 5.2.2
- **Doorstation Code DIP:** Total 4 doorstations can be supported, see 6.1
- **Main Connect Port:** To connect the bus line and the electronic locks.
- **BUS:** Connect to the bus line, no polarity.
- **PL:** External lock power input, connect to the power positive(power +).
- **S1+, S2+:** Lock power(+) output, to connect 2 locks.
- **S-:** Lock power(-) output, connect to the power(-) input of locks(only when using the camera to power the locks, if using the external power supply for the locks, the S- will not be connected).

4. Mounting

4.1 Mounting Without Rainy Cover




4.2 Mounting With Rainy Cover




4.3 Placing Name Label

Press down and move the name label to the right side, then take off the cover. Place the name paper between the cover and the transparent plastic base. then put the cover back to the panel.



5. System Wiring and Connections

5.1 Basic Connection




5.2 Electric Lock Connection

5.2.1 Door Lock Controlled with Internal Power

Note:


1. Electronic lock of Power-on-to-unlock type should be used.
2. The door lock is limited to 12V, and holding current must be less than 250mA.
3. The door lock control is not timed from Exit Button(EB)
4. The **Unlock Mode** Parameter of Monitor must be set to 0 (by default)




5.2.2 Door Lock Controlled with Dry Contact

Note:

1. The external power supply must be used according to the lock
2. The inside relay contact is restricted to AC or DC 24V/3A
3. The jumper must be taken off before connecting
4. Setup the **Unlock Mode** of Monitor for different lock types
 - Power-on-to-unlock type: Unlock Mode=0 (by default)
 - Power-off-to-unlock type: Unlock Mode=1




5.2.3 How to setup the unlock parameter in Monitor



Note:


- must connect DPC-D242 correctly before setting
- the parameter will be saved in DPC-D242 automatically, so you need only set on one monitor

5.3 Multi Doorstations Connection




5.4 Multi Monitors Connection


5.4.1 Basic IN-OUT Wiring Mode



5.4.2 With DBC-4 Wiring Mode







6.Setup





6.1 DIP Switches Settings of Doorstation

Total 2 bits on the DIP switches can be configured. The switches can be modified either before or after installation.

































Bit state	Descriptions
	Default setting, ID = 0(00), set to the first Door Station.
	ID = 1(10), set to the second Door Station.
	ID = 2(01), set to the third Door Station.
	ID = 3(11), set to the fourth Door Station.

6.2 DIP Switches Settings of Monitor

There are 6 bit switches in total. The DIP switches are used to configure the User Code for each Monitor. Bit-6 is line terminal switch, which have to be set to ON if the Monitor is in the end of the line(bus), otherwise set to OFF.

Bit state	Setting	Bit state	Setting
	The monitor is not at the end of the bus.		The monitor is at the end of the bus.

Bit-1 to Bit-5 are used to User Code setting. The value is from 0 to 31, which have 32 different codes .


Bit state	User Code	Bit state	User Code	Bit state	User Code
	Code=0		Code=11		Code=22
	Code=1		Code=12		Code=23
	Code=2		Code=13		Code=24
	Code=3		Code=14		Code=25
	Code=4		Code=15		Code=26
	Code=5		Code=16		Code=27
	Code=6		Code=17		Code=28
	Code=7		Code=18		Code=29
	Code=8		Code=19		Code=30
	Code=9		Code=20		Code=31
	Code=10		Code=21		

6.3 Notices

Name	Discription	Useage
PS5-24V	Power supply,85~260Vac input,24Vdc/3A output,10 DIN modeules	Connect with multi doorstations or multi monitors(up to 2 or above)
PS4-24V	Power supply,85~260Vac input,24Vdc/1A output,for basic kit only,4 DIN modules	Connect with one doorstation and one monitor(DT16 can be connected two)

7.Cables Requirements

The maximum distance of the wiring is limited in the DT system. Using different cables may also affect the maximum distance which the system can reach.



When Monitor quantity < 20

Cable Usage	A	B	C
Twisted cable 2x0.75 mm ²	60	60	30
Twisted cable 2x1 mm ²	80	80	40

When Monitor quantity > 20

Cable Usage	A	B	C
Twisted cable 2x1 mm ²	70	30	20
Twisted cable 2x1.5 mm ²	70	50	30

Note:If the monitor has been specified the distiance,refer to the parameter.

8.Specification

Lock Power supply:	12Vdc, 250mA(Internal Power)
Power Consumption:	1W in standby, 5W in working
NO, COM dry contact:	Max. 24V dc 3A
Unlocking time:	1 to 9 seconds, set by Monitor
Working temperature:	-10°C ~ 45°C
Dimension:	184(H)×124(W)×33(D)mm

The design and specifications can be changed without notice to the user. Right to interpret and copyright of this manual are preserved.
